



**Coriolis**  
Mass Flow Meters

## Coriolis Flow Meters

RCT1000 with RCS005...300 Sensors



**Badger Meter**

CRL-UM-00038-EN-10 (April 2019)

# User Manual



# CONTENTS

Introduction . . . . .	9
Coriolis Mass Meter . . . . .	9
Badger Meter Coriolis Mass Meter . . . . .	9
Badger Meter Software . . . . .	9
Purpose of this Document . . . . .	9
Safety . . . . .	9
Safety Symbol Explanations . . . . .	9
Safety Precautions . . . . .	10
Product Labels . . . . .	11
General Safety . . . . .	11
Hazardous Location . . . . .	11
Dimensions . . . . .	12
RCS005 Sensor Dimensions . . . . .	12
RCS008 Sensor Dimensions . . . . .	12
RCS018...RCS300 Sensor Dimensions . . . . .	13
RCTX Transmitter Dimensions . . . . .	14
RCTX Remote Mount Electronics Enclosure Dimensions . . . . .	14
RCTX Remote Mount Conduit Outlet Box Dimensions . . . . .	15
RCTN Transmitter Dimensions . . . . .	15
Installation . . . . .	18
Product Unpacking and Inspection . . . . .	18
Transporting the Meter . . . . .	18
Sensor Installation . . . . .	19
Preinstallation Considerations . . . . .	19
Sensor Mounting Positions and Locations . . . . .	20
RCS005 and RCS008 Sensor Installation . . . . .	23
Transmitter Installation . . . . .	24
RCTX Transmitters . . . . .	24
Locking the Transmitter Cover . . . . .	26
Ground/Earth Connection . . . . .	26
Earthing Using Rigid Pipe . . . . .	26
EU Earthing Without Rigid Pipe . . . . .	27
Opening the Cover and Removing the Display Board . . . . .	27

Power Connections . . . . .	28
RCTX DC Power Connections . . . . .	28
RCTN AC Power Connections . . . . .	29
RCTN DC Power Connections . . . . .	30
Inputs / Outputs . . . . .	31
RCTX TB100 Interface . . . . .	31
HART Module TB1 Interface . . . . .	31
RCTX TB101 Interface . . . . .	31
RCTX Interface Diagrams. . . . .	32
Replacing the Display Board. . . . .	33
Replacing the Covers . . . . .	33
RCTN Transmitters . . . . .	34
RCTN Interface Diagrams. . . . .	35
Transmitter-to-Sensor Connections . . . . .	37
RCTX-to-Sensor Connections . . . . .	37
RCTN-to-Sensor Connections . . . . .	37
Remote RCTX Terminal Boxes . . . . .	38
RCTN for General Safety Areas . . . . .	39
Basic Operation . . . . .	40
Using the Keypad . . . . .	40
Conventions. . . . .	40
The Active Line . . . . .	41
Button Functions Based on Location In Menus . . . . .	41
Meter Checks . . . . .	46
Startup Screens. . . . .	46
Menu Map. . . . .	47
Keyboard Lock . . . . .	48
System Passwords . . . . .	48
Default Passwords . . . . .	48
Changing a Password PIN . . . . .	49
Sensor Check . . . . .	49
Initial Zeroing Procedure. . . . .	50
Priming for Zero . . . . .	50
Zeroing the System . . . . .	50
Home Screen Setup . . . . .	51

---

Enable/Disable Hidden Menus . . . . .	51
HMI Examples . . . . .	52
Editing Parameter Units, Values and Resolution . . . . .	52
Backing Up the Transmitter . . . . .	53
Automatic Transmitter Backup . . . . .	53
Manual Transmitter Backup . . . . .	53
Transmitter Backup Using RCT Console Software . . . . .	53
Backup Enabled Parameters. . . . .	54
Reset Totals Help. . . . .	54
Flow Direction . . . . .	54
Output Configuration. . . . .	55
Current Outputs . . . . .	55
Frequency, Pulse and PWM Outputs. . . . .	56
PID. . . . .	57
Modify the PID Control Settings . . . . .	57
PID Control Explanations . . . . .	57
Enabling and Setting Values on the 4...20 mA Output Port. . . . .	58
User Alarms . . . . .	59
Communication Wiring and Setup . . . . .	60
EIA-485 Port . . . . .	60
USB Programming Port . . . . .	60
EIA-485 / Modbus RTU . . . . .	60
Optional HART Communication Card . . . . .	60
Optional Ethernet Communication Card . . . . .	60
Troubleshooting . . . . .	61
Navigation During an Alarm Condition. . . . .	61
WARNING Help . . . . .	61
Identifying System Faults. . . . .	61
Red/Green LED Diagnostics . . . . .	61
Error Messages . . . . .	63
Troubleshooting Symptoms. . . . .	64
Part Number Construction. . . . .	66
Sensors 005 and 008 ONLY. . . . .	66
Sensor Part Number (Remote Mount Transmitter Option) . . . . .	67
General Safety Transmitter Part Number (Remote Mount). . . . .	68

---

Hazardous Location Transmitter Part Number (Remote Mount) . . . . .	68
Integral Mount Transmitter with Sensor Part Number Construction. . . . .	69
Specifications. . . . .	70
System with RCS005/RCS008 Sensors. . . . .	70
Flow Rate Specifications . . . . .	70
RCS005/RCS008 Sensors Specifications. . . . .	70
System Specifications. . . . .	71
Flow Rate Specifications . . . . .	71
Sensor Specifications . . . . .	71
Transmitters . . . . .	72
Cable Kits . . . . .	73
Parameters by Address (addr). . . . .	74
Parameters by Menu Location . . . . .	79
Main Menu > Measurement. . . . .	79
Main Menu > System > Sensor . . . . .	79
Main Menu > System > IO Stat . . . . .	80
Main Menu > System > About . . . . .	80
Main Menu > Set Up > Calibration > Flow . . . . .	81
Main Menu > Set Up > Calibration > Density . . . . .	81
Main Menu > Set Up > Calibration > Temperature. . . . .	81
Main Menu > Set Up > Calibration > Driver . . . . .	82
Main Menu > Set Up > Calibration > Zero Calibration . . . . .	82
Main Menu > Set Up > Calibration > Primary . . . . .	82
Main Menu > Set Up > System IO > Current1 Setup. . . . .	83
Main Menu > Set Up > System IO > Current2 Setup. . . . .	83
Main Menu > Set Up > System IO > Current3 Setup. . . . .	84
Main Menu > Set Up > System IO > Frequency Setup. . . . .	84
Main Menu > Set Up > System IO > Com Ports . . . . .	85
Main Menu > Set Up > System IO > Relays. . . . .	85
Main Menu > Set Up > System IO > Analog Input . . . . .	85
Main Menu > Set Up > Menus . . . . .	85
Main Menu > Set Up > Program . . . . .	86
Main Menu > Set Up > Password. . . . .	86
Main Menu > Set Up > Display . . . . .	87
Main Menu > Batch . . . . .	87
Main Menu > PID. . . . .	88

---

Main Menu > Total . . . . .	88
Main Menu > Concentration . . . . .	88
Main Menu > Application . . . . .	89
Main Menu > Net Flow . . . . .	89
Main Menu > Alarms > Alarm-A . . . . .	89
Main Menu > Alarms > Alarm-B . . . . .	89
Main Menu > Alarms > Alarm-C . . . . .	90
Main Menu > Alarms > Alarm-D . . . . .	90
Main Menu > Alarms > Alarm-E. . . . .	90
Main Menu > Alarms > Alarm-F. . . . .	90
RCT Console Basics . . . . .	91
Minimum System Requirements . . . . .	91
Setup . . . . .	91
Glossary . . . . .	94





# INTRODUCTION

## Coriolis Mass Meter

As a mass flow meter, a Coriolis mass meter directly measures the mass flow, temperature and density rather than volumetric flow. Since density varies with temperature, pressure and other fluid attributes, direct measurement of mass is typically more accurate than deriving the mass from a volumetric flow meter. Because a Coriolis meter measures density, it is suitable for measuring homogeneous fluids that consist of two liquids.

In a Coriolis mass meter, there are virtually no obstructions in the fluid path making the meter more appropriate for viscous fluids. Since there are no internal moving parts, a Coriolis mass meter requires little maintenance.

## Badger Meter Coriolis Mass Meter

In addition to measuring mass flow and density, the Badger Meter Coriolis mass meter does batching and PID control that can be linked to discrete and analog inputs and outputs.

## Badger Meter Software

The RCT Console software can be installed on a computer which connects to the transmitter through the USB programming port. Along with meter configuration, the RCT Console software provides logging, trending and diagnostic capabilities. The RCT Console software is included with the Coriolis mass meter.

# PURPOSE OF THIS DOCUMENT

The purpose of this document is to guide you through the installation, wiring and configuration of the Coriolis RCT1000 flow meter. For wiring details for hazardous locations, see the "Coriolis Flow Meters RCTX Control Drawing" included with the meter or download it from [www.badgermeter.com](http://www.badgermeter.com).

# SAFETY

## Safety Symbol Explanations



Indicates a hazardous situation, which, if not avoided, *will* result in death or serious personal injury.



Indicates a hazardous situation, which, if not avoided, *could* result in death or serious personal injury.



Indicates a hazardous situation, which, if not avoided, *could* result in minor or moderate personal injury or damage to property.

## Electrical Symbol Explanations

Electrical Symbols					
Function	Direct Current	Alternating Current	Earth (Ground)	Protective Ground	Chassis Ground
Symbol					

RCT1000 transmitters employ modular construction and provide electrical safety for the operator.

## Safety Precautions

### **DANGER**

**THE POWER SUPPLY BOARD CAN HAVE LINE VOLTAGES APPLIED TO IT. DISCONNECT ELECTRICAL POWER BEFORE OPENING THE INSTRUMENT ENCLOSURE. USE WIRING PRACTICES THAT CONFORM TO LOCAL AND NATIONAL CODES WITHIN THE REGION WHERE THE PRODUCT IS INSTALLED. [FOR EXAMPLE: THE NATIONAL ELECTRICAL CODE® HANDBOOK IN THE U.S.; CANADIAN ELECTRIC (CE) CODE IN CANADA].**

### **CAUTION**

**IF THE EQUIPMENT IS USED IN A MANNER NOT SPECIFIED BY THE MANUFACTURER, THE PROTECTION PROVIDED BY THE EQUIPMENT MAY BE IMPAIRED.**

### **WARNING**

**DANGER OF BREAKAGE DUE TO CORROSIVE OR ABRASIVE FLUIDS.**

- **VERIFY THE COMPATIBILITY OF THE PROCESS FLUID WITH THE SENSOR MATERIAL.**
- **ENSURE THE RESISTANCE OF ALL FLUID-WETTED MATERIALS IN THE PROCESS.**
- **KEEP WITHIN THE SPECIFIED PRESSURE AND TEMPERATURE RANGE.**

## PRODUCT LABELS

### General Safety

All RCTN transmitters for general safety areas have the labels shown below.

### RCTN Transmitter Labels




Figure 1: RCTN label

### RCS Sensor Tags




Figure 2: RCS sensor tag example

### Hazardous Location

#### Remote Transmitter




Figure 3: Remote transmitter tag example

### Integral Sensor and Transmitter

Sensors with integral mount transmitters have a single tag on the sensor. The specific certifications listed on the tag depend on the sensor part number.




Figure 4: Hazardous location sensor tag examples

#### Remote Sensor




Figure 5: Remote sensor tag example

DIMENSIONS

RCS005 Sensor Dimensions




Figure 6: RCS005 dimensions

Sensor	Nominal Size	A	B	C	D	E	F	G
RCS005	1/4 in.	5.90 in. (149.9 mm)	5.00 in. (127 mm)	1.00 in. (25.4 mm)	3.60 in. (85.3 mm)	7.93 in. (201.7 mm)	2.42 in. (61.6 mm)	1.23 in. (31.2 mm)

RCS008 Sensor Dimensions




Figure 7: RCS008 dimensions

Sensor	Nominal Size	A	B	C	D	E	F	G	H	J
RCS008	1/4 in.	8.48 in. (215.3 mm)	5.72 in. (145.3 mm)	6.60 in. (167.7 mm)	1.50 in. (38.1 mm)	8.70 in. (221 mm)	2.67 in. (67.8 mm)	0.98 in. (24.9 mm)	4.65 in. (118 mm)	2.48 in. (63 mm)

# RCS018...RCS300 Sensor Dimensions




Figure 8: Large sensor dimensions

Sensor	Nominal Size	A <sup>1</sup>	B	C	D	E (Standard) <sup>4</sup>	E (Remote)
RCS018	1/2 in.	13.6 in. (346 mm) <sup>1</sup>	7.1 in. (180 mm) <sup>1</sup>	8.5 in. (217 mm) <sup>2</sup>	4.4 in. (113 mm) <sup>2</sup>	19.3 in. (489 mm)	18.3 in. (464 mm)
RCS025	1/2 in.	16.0 in. (406 mm) <sup>1</sup>	9.0 in. (228 mm) <sup>1</sup>	9.9 in. (253 mm) <sup>2</sup>	4.4 in. (113 mm) <sup>2</sup>	20.7 in. (525 mm)	19.7 in. (500 mm)
RCS050	1/2 in.	18.5 in. (470 mm) <sup>1</sup>	11.6 in. (296 mm) <sup>1</sup>	15.9 in. (405 mm) <sup>2</sup>	5.1 in. (131 mm) <sup>2</sup>	24.2 in. (615 mm)	23.2 in. (590 mm)
RCS100	1 in.	23.2 in. (590 mm) <sup>1</sup>	16.8 in. (426 mm) <sup>1</sup>	27.6 in. (700 mm) <sup>2</sup>	6.4 in. (163 mm) <sup>2</sup>	34.3 in. (870 mm)	33.3 in. (845 mm)
RCS200	2 in.	26.4 in. (670 mm) <sup>2</sup>	18.5 in. (472 mm) <sup>2</sup>	28.6 in. (726 mm) <sup>3</sup>	7.9 in. (203 mm) <sup>3</sup>	33.4 in. (848 mm)	32.4 in. (823 mm)
RCS300	3 in.	40.9 in. (1040 mm) <sup>2</sup>	28.7 in. (728 mm) <sup>2</sup>	40.4 in. (1028 mm) <sup>3</sup>	9.5 in. (243 mm) <sup>3</sup>	45.3 in. (1150 mm)	44.3 in. (1125 mm)

<sup>1</sup> ± 0.12 in (3 mm)

<sup>2</sup> ± 0.15 in (4 mm)

<sup>3</sup> ± 0.24 in (6 mm)

<sup>4</sup> ± 0.39 in (10 mm)

**NOTE:** End fittings can be NPT (shown), Class 150 or Class 300 ANSI flanges, or other; dimensions A and C do not change.

RCTX Transmitter Dimensions




Figure 9: RCTX dimensions

A	B	C	D	E
6.57 in. (167 mm)	5.20 in. (132 mm)	5.98 in. (152 mm)	4.57 in. ± 0.12 in. (116 mm ± 3 mm)	1.37 in. (35 mm)

RCTX Remote Mount Electronics Enclosure Dimensions




Figure 10: RCTX remote mount dimensions

A	B	C	D	E
6.57 in. (167 mm)	5.20 in. (132 mm)	13.43 in. (341 mm)	4.57 in. ± 0.12 in. (116 mm ± 3 mm)	1.37 in. (35 mm)

## RCTX Remote Mount Conduit Outlet Box Dimensions




Figure 11: Conduit outlet box for remote mount

A	B	C	D
4.5 in. (116 mm)	3.75 in. (95 mm)	2.4 in. (62 mm)	0.75 in. (19 mm)

## RCTN Transmitter Dimensions

**NOTE:** Mounting hardware included (wall mount bracket, pipe mount bracket and transmitter/bracket fasteners)




Figure 12: Transmitter mounting dimensions

A	B	C	D	E	F
9.80 in. (249.9 mm)	8.00 in. (203.2 mm)	10.30 in. (261.6 mm)	4.30 in. (109.2 mm)	3.66 in. (93.0 mm)	8.32 in. (211.2 mm)




Figure 13: Back plate mounting

1	Screw	#8-32 UNC-2B
---	-------	--------------




Figure 14: Pipe mounting

1	Screw	#8-32 UNC-2B
2	Bracket	Pipe mounting






Figure 15: Pipe mounting dimensions

A	B	C	D	E	F	G	H
5.50 in. (139.7 mm)	4.00 in. (101.6 mm)	1.11 in. (28.2 mm)	0.625 in. (15.9 mm)	1.25 in. (31.8 mm)	3.80 in. (96.5 mm)	5.25 in. (133.6 mm)	6.00 in. (152.4 mm)

## INSTALLATION

In general, the following steps are required to install and put the meter into service.

1. Unpack meter components and transport to the installation location.
2. Install the transmitter and sensor.
3. Connect the signal cable between the transmitter and the sensor, if necessary.
4. Install any required I/O wiring.
5. Wire power to the transmitter.
6. Power up the transmitter.
7. Perform initial zeroing of the meter.
8. Perform firmware setup starting at the *Home* screen.
9. Put the meter into service.

## PRODUCT UNPACKING AND INSPECTION

Upon receipt of the product, perform the following unpacking and inspection procedures.

**NOTE:** If damage to the shipping container is evident upon receipt, request the carrier to be present when the product is unpacked.

Carefully open the shipping package and follow any instructions that may be marked on the exterior. Remove all cushioning material surrounding the product and carefully lift the product from the package.

Retain the package and all packing material for possible use in reshipment or storage.

Visually inspect the product and applicable accessories for any physical damage such as scratches, loose or broken parts or any other sign of damage that may have occurred during shipment.

**NOTE:** If damage is found, request an inspection by the carrier's agent within 48 hours of delivery and file a claim with the carrier. A claim for equipment damage in transit is the sole responsibility of the purchaser.

## TRANSPORTING THE METER

The following instructions apply to transporting the meter to its final installation point:

- Transport the devices in the shipping containers in which they came.
- Do not remove covers or caps fitted to the process connections until immediately before installation. The covers prevent mechanical damage to the sealing faces and the ingress of foreign matter into the measuring tube during transportation and storage.
- Do not lift assembled metering systems by the transmitter housing. Use webbing slings attached around the two process connections. Do not use chains, as they could damage the housing.

### **⚠ WARNING**

**THERE IS A RISK OF INJURY IF THE MEASURING DEVICE SLIPS. THE CENTER OF GRAVITY OF THE ASSEMBLED MEASURING DEVICE MIGHT BE HIGHER THAN THE POINTS AROUND WHICH THE SLINGS ARE ATTACHED. AT ALL TIMES, THEREFORE, MAKE SURE THE DEVICE DOES NOT UNEXPECTEDLY TURN AROUND ITS AXIS OR SLIP.**




Figure 16: Transport sling

## SENSOR INSTALLATION

Before installation, configuration or operation, familiarize yourself with the equipment and operating requirements by reading all sections of this manual. Make sure the site has been thoroughly prepared and is suitable for installation.

### Preinstallation Considerations

#### IMPORTANT

**Remove all process connection caps and make sure process connections are open.**

- Support and align piping connections to prevent side loading of the mating surfaces.
- RCS018 and larger sensors are designed to be supported by the process flange connection. No additional supports are needed for meter housing.
- To reduce the influence of pipe vibration on RCS018 and larger meters, use Stauff style clamps to help with supporting process piping.
- Mount full port ball valves (isolation valves) on either side of the meter for zero calibration purposes.
- Mount control valves downstream of the flow meter to prevent possible cavitation, especially when measuring liquids with low boiling points (see Figure 17).
- Install the sensor in a section of the piping where it always remains full, unless the application is designed to drain with no flow.
- Vertical piping installations should have the flow going up through the sensor. See Figure 25 on page 22.
- When using hose connections, use a short section of rigid pipe on each side of the sensor for proper support. The sensor should not hang from hose connections. See Figure 23 on page 21 and Figure 24 on page 21).
- Use caution with fluids that harden or solidify at rest. Do not pass fluids that react together through the same flow sensor. Do not cover transmitter with insulation material.
- If heat tracing is used, be aware of the maximum temperature limits of the meter.
- Use of armored hoses as sensor vibration isolators may be required when a high amount of ambient vibration is present (see Figure 23 on page 21 and Figure 24 on page 21).
- Verify that particulate matter is small enough to pass through the flow sensor. Add a filter to the system, if necessary.
- Verify that the flow sensor is earthed/grounded at the earth connector located on the sensor side. An AWG #10 or larger protective ground must be connected to the side grounding terminal for the system to work correctly (see Figure 23 on page 21, Figure 22 on page 21 and Figure 25 on page 22).
- Avoid high sources of EMF that can be produced by large transformers, large motors and VFDs without chokes.




Figure 17: Control valve location




Figure 18: Purge ports

1	Port	Nitrogen purge
---	------	----------------

#### **⚠ WARNING**

**THE SENSOR IS PURGED WITH DRY NITROGEN AT THE FACTORY. THE TWO PURGE PLUGS SHOULD NOT BE REMOVED. IF THEY ARE REMOVED FOR ANY REASON, RETURN THE UNIT TO THE FACTORY TO BE RE-PURGED AND SEALED. CONSULT FACTORY FOR SUPPORT.**

Sensor Mounting Positions and Locations

- Always mount the sensor downstream of the flow.
- Use vibration-reducing pipe supports approximately 3 and 6 pipe diameters from the end of the sensor in all applications.
- Install the sensor in a section of the piping where it always remains full, unless the application is designed to drain with no flow. See Figure 25 on page 22.

Vertical Mounting with Tubes to the Side, Flow Going Down

The mounting orientation shown in Figure 20 is recommended for installation in an open vertical pipeline. If you MUST use this configuration, make sure to use an isolation valve or other pipe restriction to prevent the sensor from running empty while measurement is being taken.




Figure 19: Mounting positions and locations




Figure 20: Tubes to the side with flow going down)

Horizontal Mounting with Tubes Down

The mounting orientation shown in Figure 21 is recommended for liquid applications.




Figure 21: Tubes down (liquids)

1	Supports— <b>Customer supplied</b>	Rigid pipe supports approximately 3 and 6 pipe diameters from the end of the sensor
2	Isolation Valves— <b>Customer supplied</b>	Full port ball
3	Ground	Protective (earth), 10 AWG (4 mm²) minimum

### Horizontal Mounting with Tubes Up

The mounting orientation shown in *Figure 22* is recommended for gas or slurry applications where condensate may exist.




Figure 22: Tubes up (gases and slurries)

1	Supports— <b>Customer supplied</b>	Rigid pipe supports approximately 3 and 6 pipe diameters from the end of the sensor
2	Isolation Valves— <b>Customer supplied</b>	Full port ball
3	Ground	Protective (earth), 10 AWG (4 mm <sup>2</sup> ) minimum

### Horizontal Position with Flexible Armored Hoses




Figure 23: Flexible armored hoses

1	Supports— <b>Customer supplied</b>	Rigid pipe supports approximately 3 and 6 pipe diameters from the end of the sensor
2	Hose— <b>Customer supplied</b>	Flexible armored
3	Isolation Valves— <b>Customer supplied</b>	Full port ball

### Horizontal Position with Flexible Armored Hose Loops




Figure 24: Flexible armored hose loops

1	Supports— <b>Customer supplied</b>	Rigid pipe supports approximately 3 and 6 pipe diameters from the end of the sensor
2	Hose— <b>Customer supplied</b>	Flexible armored
3	Isolation Valves— <b>Customer supplied</b>	Full port ball

Vertical Mounting with Tubes to the Side, Flow Going Up

The mounting orientation shown in *Figure 25* is recommended for self-draining configurations.




Figure 25: Tubes to the side with flow going up (self-draining)

1	Supports— <b>Customer supplied</b>	Rigid pipe supports approximately 3 and 6 pipe diameters from the end of the sensor
2	Isolation Valves— <b>Customer supplied</b>	Full port ball
3	Ground	Protective (earth), 10 AWG (4 mm <sup>2</sup> ) minimum

## RCS005 and RCS008 Sensor Installation

The mounting orientation for the RCS005 and RCS008 sensors is identical. The RCS008 is shown *Figure 26*.




Figure 26: RCS008 mounting

1	Valves— <b>Customer supplied</b>	Full port ball
2	Clamp— <b>Customer supplied</b>	Pipe
3	Screw	Grounding 1/4–20
4	Ground— <b>Customer supplied</b>	Protective (earth), 10 AWG (4 mm <sup>2</sup> ) minimum
5	Plate— <b>Customer supplied</b>	Mounting
6	Pipe or hose— <b>Customer supplied</b>	Mounting

**NOTE:** Vibration isolators are recommended on the mounting feet.

## TRANSMITTER INSTALLATION

For wiring details, see the "Coriolis Flow Meters RCTX Control Drawing" included with this meter, or download it from [www.badgermeter.com](http://www.badgermeter.com).

### RCTX Transmitters

The RCTX transmitter is either integrated into the sensor or mounted remotely from the sensor. Install the transmitter in an area convenient for observing the LCD readout (RCTX with Display ONLY), programming and servicing.

- Transmitter/Sensor for hazardous locations
- Mount where little vibration exists
- Mount where protected from corrosive fluids
- Transmitter's ambient temperature limits – 4...140° F (–20...60° C)
- Keep out of direct sunlight. Direct sunlight may increase transmitter temperature above maximum temperature
- Allow enough room for maintenance and conduit entrances

### RCTX with Display ONLY



**OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC-SENSITIVE DEVICES.**

The display is designed to be oriented in any 90-degree position based on the orientation of the transmitter/sensor.

#### **To rotate the orientation of the display board:**

1. Turn off power to the unit.
2. Turn the cover counterclockwise to unscrew it.
3. Use a Phillips screwdriver to remove the 4 screws holding the display board (hold display board as the last screw is removed so the board does not drop down when mounted vertically).
4. Re-position the display board and secure with the four screws.
5. Install the cover.

**NOTE:** Use 3/4 inch 14NPT fittings/plugs to maintain the explosion-proof integrity of the enclosure.




Figure 27: Display board rotated 90°



### RCTX Transmitters with Integral Mount

**To rotate the orientation of the transmitter relative to the sensor:**

1. Loosen the 1-3/4 in. union hex nut. Be careful to not loosen the feedthrough to the enclosure.
2. Turn the transmitter. Do not turn beyond 180 degrees.
3. When the orientation is correct, tighten the nut to wrench tight.

**To route the power cables:**

Route the power and I/O cables into the transmitter via the explosion-proof conduit holes located on each side of transmitter housing.




Figure 28: Sensor with integrated RCTX transmitter

### RCTX Transmitters with Remote Mount

Route the power and I/O cables into the transmitter via the explosion-proof conduit holes located on each side of transmitter housing.

**NOTE:** Use 3/4 inch 14NPT fittings/plugs to maintain the explosion-proof integrity of the enclosure.




Figure 29: Sensor with remote RCTX transmitter

## Locking the Transmitter Cover

To prevent the cover from loosening due to vibration, tighten the setscrew into the enclosure. See *Figure 30*.

To lock the cover on the transmitter housing, remove the setscrew and thread a customer-supplied chain or cable through the setscrew hole and the hole on the nearest tab. See *Figure 30*.




Figure 30: Securing the enclosure cover

## GROUND/EARTH CONNECTION

### IMPORTANT

**All wiring must be suitable for a temperature of at least 203° F (95° C).**

To access terminal blocks for wiring:

- RCTX without display: Remove the cover.
- RCTX with display: Remove the cover and the display board.
- RCTN: Loosen the four screws in the enclosure door and open.

**NOTE:** The sensor cable carries low voltage, high sensitivity signals. Do not add additional length to the cable supplied with the transducers. If additional cable is required, contact the factory to arrange an exchange for a transducer cable with the appropriate length. Cables up to 300 ft (91 meters) are available.

### Earthing Using Rigid Pipe

#### **⚠ WARNING**

**FOR RCTX TRANSMITTERS, USE A POSITIVE GROUNDING RIGID PIPE CONNECTOR. THIS CONNECTOR ACTS AS A PROTECTIVE GROUND AND MUST BE CONNECTED TO AN APPROPRIATE GROUNDING LOCATION.**

#### **⚠ WARNING**

**FOR RCTN TRANSMITTER, THE POWER CONNECTIONS MUST USE THE CONDUIT HOLE ON THE FAR RIGHT AND A POSITIVE GROUNDING RIGID PIPE CONNECTOR. THIS CONNECTOR ACTS AS A PROTECTIVE GROUND AND MUST BE CONNECTED TO AN APPROPRIATE GROUNDING LOCATION.**

## EU Earthing Without Rigid Pipe

### General

All wiring practices should comply to the NEC Article 500 or Canadian Electrical Code (CEC) Part I and Part II or IEC 60079-14 as required by local and/or national codes.

### Connecting or disconnecting devices:

- Make sure the supply voltage is switched off and the transmitter is in a non-hazardous area.
- Use connecting cables rated for a continuous service temperature of  $-10 \dots 95^{\circ}\text{C}$  ( $T_{\text{amb max}} + 20^{\circ}\text{C}$ ).
- Use only certified (conforming to IEC 60079-14 Electrical Installations in Hazardous Areas) cable glands and conduit hole plugs.
- Seal unused entry holes with approved sealing plugs that correspond to the type of protection NEMA 4 or IP66 as required for the installation area. The sealing plugs included with the transmitter meet this requirement and are compliant to both standards.

### Potential equalization (earth bonding)

As a condition of safe use, both an internal and external earth bond are required.

- Internal earth bond is made at the protective earth terminal on terminal block TB101 (for RCTX) or TB1 (for RCTN). Earth bond conductors must be the same gauge or larger than the power supply conductors.
- The external bond is satisfied by connecting the enclosure chassis through hard conduit or a ground lug.




Figure 31: Typical earth bonding connector

## OPENING THE COVER AND REMOVING THE DISPLAY BOARD



### **OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC-SENSITIVE DEVICES.**

1. Turn off power to the unit.
2. Grasp the enclosure cover and turn it counter-clockwise until it separates from the enclosure body. Set the cover aside.
3. Use a Phillips screwdriver to remove the 4 screws holding the display board to the standoffs (hold display board as the last screw is removed so the board does not drop down when mounted vertically). See Figure 32.
4. Gently turn over the display board.
5. Open the tabs on the header assembly to release the cable ribbon connector. See Figure 33.
6. Remove the display board.




Figure 32: Phillips head screws




Figure 33: Release cable ribbon

## POWER CONNECTIONS

### RCTX DC Power Connections

**NOTE:** Use a small bladed screwdriver to secure wires to the connectors.

For wiring details, see the "Coriolis Flow Meters RCTX Control Drawing" included with the meter or download it from [www.badgermeter.com](http://www.badgermeter.com).

The RCTX operates from a 18...28V DC Class 2 source, as long as the source is capable of supplying a minimum of 7W.

1. Connect an 18...28V DC Class 2 power source as illustrated in the schematic in *Figure 34*. Terminal blocks in the RCTX accommodate wire gauges up to 16 AWG.
2. A switch or circuit breaker is required in the installation.
  - a. The switch or circuit breaker must be in close proximity of the RCTX and within easy reach of the operator.
  - b. The switch or circuit breaker must be marked as the disconnect device for the RCTX.

**NOTE:** DC power input is protected with an internal 1.5 Amp, Slo-Blo, surface mount (non-field serviceable) fuse. This fuse protects only for a catastrophic failure and must be returned to factory for servicing if blown.

**NOTE:** User shall provide external circuit breaker at the source for normal operation.

**NOTE:** RCTX with Display: Must remove display board for terminal block access.

**TB100** (See *Figure 34*.)

1 VIN (Power Source 18...28V DC)

2 VCOM (Power Source Common)




Figure 34: Wiring reference: RCTX with display shown and display board removed for clarity

## RCTN AC Power Connections

1. Verify that switch S1, the AC power selection switch, is set to the appropriate line voltage. The RCTN can be set for either 115V AC or 230V AC. See *Figure 35*.
2. The RCTN is shipped with a fuse installed that is designed for 115V service and contains a 0.25 A fuse. If the RCTN is to be operated at 230V AC, replace the fuse in F1 with a 0.125 A slow blow fuse 5 x 20 mm (a 0.125 A fuse is included with the meter).
3. Connect power to the screw terminal block TB1 in the RCT1000 transmitter using the conduit hole on the right side of the enclosure. Connect 115 or 230V AC, AC neutral and protective ground to the TB1 terminals referenced in *Figure 35*. Do not operate without a protective (earth) ground connection. Install using wiring practices that conform to regional, local and national codes (for example, The National Electrical Code Handbook in the U.S.; Canadian Electric (CE) Code in Canada).
4. See *Figure 35* for AC connection schematic. Terminal blocks in the RCT1000 accommodate wire gauges up to 14 AWG.
5. A switch or circuit breaker is required in the installation.
6. The switch or circuit breaker must be in close proximity of the RCT1000 and within easy reach of the operator.
7. The switch or circuit breaker must be marked as the disconnect device for the RCT1000.

### ⚠ WARNING

- **AS A CONDITION OF SAFE USE, AN EARTH BONDED METAL CONDUIT MUST BE USED ON A MINIMUM OF ONE WIRE ENTRANCE HOLE.**
- **DO NOT OPEN ENCLOSURE WHEN ENERGIZED.**
- **DO NOT REMOVE OR REPLACE FUSE WHEN ENERGIZED.**

### ⚠ CAUTION

**ANY OTHER WIRING METHOD MAY BE UNSAFE OR CAUSE IMPROPER OPERATION OF THE INSTRUMENT.**




Figure 35: NEMA 4 AC power connections

1	Switch	S1–AC Power selection	4	Connector	Grounding
2	Fuse	F1–For 115V AC input use 0.250 A F1–For 230V AC input use 0.125 A	5	Ground	External
3	Disconnect	Switch or circuit breaker	6	Terminal block	TB1–AC Power connections

**NOTE:** This instrument requires clean electrical line power. Do not operate this unit on circuits with electrically noisy components such as fluorescent lights, relays, compressors or variable frequency drives and similar devices. Do not use a step down transformer from high voltage, high amperage sources. Do not run signal wires with line power conductors within the same wiring tray or conduit.

RCTN DC Power Connections

The RCT1000 operates from a 18...28V DC Class 2 source, as long as the source is capable of supplying a minimum of 7W.

- 1. Connect a 18...28V DC Class 2 power source as illustrated in the schematic in *Figure 36*. Terminal blocks in the RCT1000 accommodate wire gauges up to 14 AWG.
- 2. A switch or circuit breaker is required in the installation.
  - a. The switch or circuit breaker must be in close proximity of the RCTN and within easy reach of the operator.
  - b. The switch or circuit breaker must be marked as the disconnect device for the RCTN.

**NOTE:** DC powered connections are protected by an automatically resetting fuse. This fuse does not require replacement.




Figure 36: NEMA 4 DC power connections

1	Terminal block	TB2-DC power connections	3	Connector	Grounding
2	Disconnect	Switch or circuit breaker	4	Ground	External

## INPUTS / OUTPUTS

The transmitter powers the current loop. Applying power from any other external device or load will result in damage to the transmitter.

**NOTE:** The *IOut1* (HART Option), *IOut2*, and *IOut3* designations can represent any parameters. Units of measure are (appropriately) different.

The frequency/pulse output signal is available as open drain (100 mA sinking max.). This channel is user-selected to operate as a straight frequency output, a pulse output or a PWM output suitable for totalizing.

The two digital output signals are available as open drain (100 mA sinking max.). Each open drain output requires a pullup resistor to DC voltage of 5...28V DC to form a positive voltage pulse. Make this connection in the users' equipment, since the preferred voltage should be available there.

The three digital inputs (DC voltage of 5...28V DC) are used to initiate many of the transmitter's advanced functions.

The analog input (0...5V maximum) is used to form a ratio between the analog input and an analog signal from other devices.

### RCTX TB100 Interface

Terminal	Signal Name	Dir	Signal Description
1	18-28Vdc	In	18...28V DC, 15W max.
2	Vdc Common	In	Power Source Common <b>NOTE:</b> This is NOT same signal as GND. This signal is isolated by an internal common mode filter choke from GND
3	RS485+	I/O	RS485+ Communications (Diff Pair)
4	RS485-	I/O	RS485- Communications (Diff Pair)
5	In_Status_1	In	Digital Input (Low: 0V DC, Active High: 5...28V DC)
6	In_Status_2	In	Digital Input (Low: 0V DC, Active High: 5...28V DC)
7	In_Status_3	In	Digital Input (Low: 0V DC, Active High: 5...28V DC)
8	GND	—	Signal GND (GND for all signals with the exception of power in)
9	Out_Status_1	Out	Digital Open Drain Output. Requires an external pullup resistor to 5...28V DC max. to provide a positive voltage level (100 mA max. sink current)
10	Out_Status_2	Out	Digital Open Drain Output. Requires an external pullup resistor to 5...28V DC max. to provide a positive voltage level (100 mA max. sink current)
11	Frequency Output	Out	Digital Open Drain Output. Requires an external pullup resistor to 5...28V DC max. to provide a positive voltage level. (10k Hz max. frequency)
12	Analog In1	In	Analog Input, 0...5V max.
13	IOut2	Out	Analog Output, 4...20mA (500 Ohm load max.) active
14	IOut3	Out	Analog Output, 4...20mA (500 Ohm load max.) active

### HART Module TB1 Interface

Transmitter must be ordered with HART card installed.

Terminal	Signal Name	Dir	Signal Description
1	IOut1	Out	Analog Output, 4...20mA (500 Ohm load max.)/HART communications
2	GND	—	Signal GND (GND for all signals with the exception of power in)

### RCTX TB101 Interface

Terminal	Signal Name	Dir	Signal Description
1	CHASSIS GND	—	Electrical conductivity via internal standoffs to RCTX enclosure. Termination for cable shields
2	CHASSIS GND	—	Electrical conductivity via internal standoffs to RCTX enclosure. Termination for cable shields

RCTX Interface Diagrams




Figure 37: Typical status\_in 1, 2 and 3 interface




Figure 38: Typical status\_out 1, 2 and frequency output interface




Figure 39: Typical IOut2 and IOut3 current interface




Figure 40: Typical IOut1 HART interface



## Replacing the Display Board



**OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC-SENSITIVE DEVICES.**

1. Turn off power to the unit.
2. Grasp the enclosure cover and turn it counter-clockwise until it separates from the enclosure body. Set the cover aside.
3. Use a Phillips head screwdriver to remove the 4 screws holding the display board to the standoffs. See *Figure 41*.
4. Gently turn over the display board.
5. Open the tabs on the header assembly to release the cable ribbon connector. See *Figure 42*.




Figure 41: Phillips head screws




Figure 42: Release cable ribbon

6. Attach the cable ribbon connector to the header assembly of the new display board.
7. Fold the cable ribbon between the standoffs to avoid pinching it with the new board.
8. Secure the display board with the 4 Phillips head screws removed in step 3.
9. Replace the cover.

## Replacing the Covers

Turn the covers clockwise and hand-tighten.




Figure 43: RCTX

Figure 44: RCTX with display

**NOTE:** If the optical buttons are not working properly, check that the windowed cover is fully tightened. The buttons will not activate if the window is too far away.

## RCTN Transmitters

The RCTN has three analog outputs available to send signals to peripheral devices (such as loop-powered remote indicators, controllers and similar equipment). Using the keypad or the RCT Console software for any range between 0...22 mA, the user may independently set these outputs. The default is 4...20 mA. The maximum load (loop) impedance for each output is 500  $\Omega$ .

Normally the lout1 output is set for mass flow. However, this output can represent other parameters. In these cases, the units of measure are (appropriately) different.

**NOTE:** The transmitter powers the current loop. Applying power from any other external device or load will result in damage to the transmitter.

The frequency/pulse output signal is available as an open collector. This channel is user selected to operate as either a straight frequency output, a pulse output or a PWM output suitable for totalizing.

**NOTE:** The maximum current-sinking capacity of the outputs is 100 mA.

**NOTE:** The open collector output requires a DC voltage of 5...28V DC and a pullup resistor to form a positive voltage pulse. It is preferable to make this connection in the users' equipment since the preferred voltage should be available there.

Outputs	Qty	Labeled	Use
<b>4-20 mA</b>	<b>3</b>	lout1 lout2 lout3	The current output reports the configured process variable. The current output parameters control how the process variable reports. Sends signals to peripheral devices such as loop-powered remote indicators, controllers and similar equipment.
<b>Frequency</b>	<b>1</b>	Freq Out	The frequency output can be configured for frequency, pulse or PWM and reports a process variable to counters or totalizers.
<b>Status</b>	<b>4</b>	Out Status 1 Out Status 2 Out Status 3 Out Status 4	An output status event is used to provide notification of process changes and, optionally, to perform specific transmitter actions if the event occurs. An output status event occurs if the real-time value of a user-specified process variable moves above a high setpoint or below a low setpoint. Output status events can also be programmed to occur when a process is within a user-defined range or out of a user-defined range with respect to two user-defined setpoints.
<b>DC Out</b>	<b>1</b>	+DC Out	Unregulated DC supply that can be used to internally power frequency out and status I/O outputs.
Inputs	Qty	Labeled	Use
<b>Status</b>	<b>4</b>	In Status 1 In Status 2 In Status 3 In Status 4	Status inputs are digital signals used to initiate many of the transmitters advanced functions.
<b>Analog In</b>	<b>2</b>	Analog In Analog In 2	Used to form ratio between the analog input and an analog signal from other devices such as flow, temperature, density, pressure and others.

Table 1: RCTN input/output listing

## RCTN Interface Diagrams




Figure 45: 4 –20 mA current output

1		Representation of internal I/O circuit
2	Load	500 $\Omega$ maximum




Figure 46: Status inputs and outputs internally powered

1	Resistor	Pullup
2		Representation of internal I/O circuit
3	External device	PLC, pulse counter or other compatible inputs




Figure 47: Frequency output internally powered




Figure 48: Status inputs and outputs externally powered

1	Output representation	50% duty cycle, 63...10k Hz maximum frequency
2		Representation of internal I/O circuit
3	Load	External frequency input device

1	Resistor	Pullup
2		Representation of internal I/O circuit
3	External device	PLC, pulse counter or other compatible inputs




Figure 49: Frequency output externally powered




Figure 50: 0...5 Volt input

1	Output representation	50% duty cycle, 63...10k Hz maximum frequency
2		Representation of internal I/O circuit
3	Load	External frequency input device

1	Input	0...5V DC
---	-------	-----------

To preserve environmental sealing of the RCTN, a specific fastener tightening pattern and torque setting is required. Tighten the captive fasteners to a torque setting of 20 in-lb. Follow the pattern in *Figure 51*.




Figure 51: Fastener tightening pattern

## TRANSMITTER-TO-SENSOR CONNECTIONS

### RCTX-to-Sensor Connections


Integral RCTX transmitters are prewired to the sensor at the factory (no wiring required).

Remotely mounted RCTX transmitters must be wired to the sensor during installation. The sensor wiring in the main transmitter enclosure is prewired. If the cable must be replaced, open the contact on the terminal block, insert a small tool or screwdriver and slide toward the wire opening.

**NOTE:** The black wire with the ring connector terminates at the transmitter. The thicker white wire terminates at the sensor.

### RCTN-to-Sensor Connections

1. Plug the cable connector into the sensor, then rotate the connectors locking ring clockwise until it seats.
2. Slide the protective cable cover over the sensor connections and thread the cover hand tight. See *Figure 52*.
3. Tighten the cable grip tight enough to hold the sensor cable firmly.
4. Route the sensor cable back to the transmitter avoiding spurious signal producing sources.
5. Insert the sensor cable through the weather resistant connector.
6. Guide the sensor cable and weather resistant connector through the transmitter conduit hole located in the bottom left of the RCTN enclosure.
7. Secure the weather resistant connector with hardware supplied.
8. Remove any protective covers from the interface board.
9. Unplug the ten-pin connector on the interface board and attach the sensor cable to the appropriate wire color codes. See *Figure 54*.
10. If an external PT100 RTD is used, connect the RTD to the three-pin plug adjacent to the Coriolis sensor plug.
11. Replace any protective covers and close the enclosure.
12. All RCS sensors are equipped with a 1/4 in. threaded ground stud. Connect this stud to a protective (earth) ground with a minimum of a 10 AWG conductor. See *Figure 26 on page 23* and *Figure 54 on page 39*.



1	Grip	Cable
2	Connection	Sensor (male)
3	Ground	Protective (earth), 10 AWG (4 mm <sup>2</sup> ) minimum
4	Connection	Cable (female)
5	Cable	Interconnect
6	Cover	Cable (protective)

Figure 52: Remote mounted hazardous location sensor

## Remote RCTX Terminal Boxes

The sensor wiring in the main transmitter enclosure is prewired. If the cable must be replaced, open the contact on the terminal block, insert a small tool or screwdriver and slide toward the wire opening.




Figure 53: Remote RCTX terminal boxes

Figure 1 illustrates the RTD connection diagrams. It shows three different RTD sensor modules (1, 2, 3) and their connection to a 100 ohm RTD (4). A detailed view of the internal wiring shows the RTD connected to the internal RTD (5) and the internal RTD connected to the internal RTD (6). A legend identifies the colors: 1 N/C, 2 Brown, 3 Yellow, 4 Gray, 5 Blue, 6 Orange, 7 Green, 8 Violet, 9 White, 10 Red, Screw Black, Shield.

## BASIC OPERATION

### Using the Keypad

The buttons are used individually to execute a command or effect a change, according to the mode of the firmware. Button presses are time sensitive. The firmware recognizes two button press durations known as *Press* and *Long Press*. A *Press* lasts for less than two seconds. A *Long Press* lasts longer than two seconds.

### Conventions





Button Name	Button Icon	Functions
Menu/Exit		Shows the menu system from the <i>Home</i> screen. If the user is in the menu system, Menu/Exit returns to the parent menu of the displayed menu/parameter. During editing, a Long Press cancels the editing without any value change. During editing, a short Press changes the value to zero. If <i>WARNING</i> is shown in 4 <sup>th</sup> line, then a short Press shows the <i>WARNINGS</i> screen. If <i>WARNING</i> is shown in 4 <sup>th</sup> line, then a Long Press returns the user to the parent screen or allows the user to enter the menu system from the <i>Home</i> screen.
Up Arrow		In parameter value editing mode, a Long Press moves the cursor one position to the right and a short Press changes a character. In menus and parameter lists, a short Press moves a menu or parameter list up.
Down Arrow		In parameter value editing mode, a Long Press moves the cursor one position to the left and a short Press changes a character. In menus and parameter lists, a short Press moves a menu or parameter list down.
Enter		If a menu item is shown in the active line, then a short Press enters into that menu. If a parameter is shown in the active line, then a Long Press starts parameter value editing mode if the parameter's access rights and the set password allow it. If a parameter is edited, then a Long Press closes the parameter editor and saves any new change.

Table 2: Keyboard icons

### RCTX

The optical buttons on the hazardous location RCTX transmitter may be locked to prevent accidental activation of the buttons. To unlock, press the Up arrow, Down arrow, Menu/Exit and Enter buttons sequentially. The Lockout function can be enabled or disabled through parameter KbLock (303).

If the optical buttons are not working properly, check that the windowed cover is fully tightened. The buttons will not activate if the window is too far away.

### RCTN

#### WARNING

**DO NOT USE SHARP OBJECTS TO ACTIVATE/PRESS THE BUTTONS.**



## The Active Line

The RCT1000 uses the concept of the Active line to make changes to the transmitter's instructions. The active line is the topmost line on the display and whatever parameter or menu is on the active line can be edited or stepped into.

**NOTE:** The active line is only used in editing mode or menu navigation.








Figure 56: The active line





## Button Functions Based on Location In Menus





Keypad Functions from the Home Screen (Without Warnings)			
Button	Press Duration	Function	Notes
	Press	Steps into the top level menu screen.	
	Long Press		
	Press	Scrolls the user defined parameters upward.	
	Long Press		
	Press	Scrolls the user defined parameters downward.	
	Long Press		
	Press	Performs no action.	
	Long Press	Edits parameter in active line assuming password access allows it.	





  





Keypad Functions from the Home Screen (With Warnings)			
Button	Press Duration	Function	Notes
	Press	Shows the warnings screen.	
	Long Press	Steps into the top level menu system.	
	Press	Scrolls the user defined parameters upward.	If not within warning screen.
	Long Press		
	Press	Scrolls the user defined parameters downward.	If not within warning screen.
	Long Press		
	Press	Performs no action.	
	Long Press	Edits parameter in active line assuming password access allows it.	





Keypad Functions from the Top Level Main Menu Screen (Without Warnings)			
Button	Press Duration	Function	Notes
	Press	Returns user to <i>Home</i> screen.	
	Long Press		
	Press	Scrolls the list of available menus upward.	
	Long Press		
	Press	Scrolls the list of available menus downward.	
	Long Press		
	Press	Steps into the menu shown on the active line.	
	Long Press		





Keypad Functions from the Top Level Main Menu Screen (With Warnings)			
Button	Press Duration	Function	Notes
	Press	Shows the warning screen.	
	Long Press	Returns the user to the home screen.	
	Press	Scrolls the list of available menus upward.	If not within warning screen.
	Long Press		
	Press	Scrolls the list of available menus downward.	If not within warning screen.
	Long Press		
	Press	Steps into the menu shown on the active line.	
	Long Press		

Keypad Functions from Submenus (Without Warnings)			
Button	Press Duration	Function	Notes
	Press	Returns user to the parent menu.	
	Long Press		
	Press	Scrolls the list of available submenus upward.	
	Long Press		
	Press	Scrolls the list of available submenus downward.	
	Long Press		
	Press	Steps into the menu shown on the active line.	
	Long Press		





Keypad Functions from Submenus (With Warnings)			
Button	Press Duration	Function	Notes
	Press	Shows the warning screen.	
	Long Press	Returns user to the parent menu.	
	Press	Scrolls the user defined submenus upward.	If not within warning screen.
	Long Press		
	Press	Scrolls the user defined submenus downward.	If not within warning screen.
	Long Press		
	Press	Steps into the menu shown on the active line.	
	Long Press		





Keypad Functions from the Parameter Screens (Without Warnings)			
Button	Press Duration	Function	Notes
	Press	Returns user to the parent menu.	
	Long Press		
	Press	Scrolls the parameter list upward.	
	Long Press		
	Press	Scrolls the parameter list downward.	
	Long Press		
	Press	Performs no action.	
	Long Press	Initiates the editing function for the parameter in the active line.	





Keypad Functions from the Parameter Screens (With Warnings)			
Button	Press Duration	Function	Notes
	Press	Shows the warning screen.	
	Long Press	Returns user to the parent menu.	
	Press	Scrolls the parameters list upward.	If not within warning screen.
	Long Press		
	Press	Scrolls the parameters list downward.	If not within warning screen.
	Long Press		
	Press	Performs no action.	
	Long Press	Initiates the editing function for the parameter in the active line.	

Keypad Functions from the Parameter Edit Screens (Without Warnings)			
Button	Press Duration	Function	Notes
	Press	Clears the edited value to +0.	
	Long Press	Cancels edit(s) and returns to the parameter screen.	
	Press	<b>Values:</b> Increment. <b>Resolution:</b> Increment. <b>Units:</b> Scrolls available list upward.	
	Long Press	Moves the cursor to the right if the value is being edited.	
	Press	<b>Values:</b> Decrement. <b>Resolution:</b> Decrement. <b>Units:</b> Scrolls available list downward.	
	Long Press	Moves the cursor to the left if the value is being edited.	
	Press	Cycles through editing areas (value, resolution and units).	Does nothing for list type parameters.
	Long Press	Saves any changes and returns user to the parent parameter screen.	

Keypad Functions from the Parameter Edit Screens (With Warnings)			
Warnings cannot be handled when in editing mode.			

Keypad Functions from the Parameter Edit Screens (List Type) (Without Warnings)			
Button	Press Duration	Function	Notes
	Press	Reverts to the first selection on the list.	
	Long Press	Cancels edit(s) and returns to the parameter screen.	
	Press	Scrolls the list options upward.	
	Long Press		
	Press	Scrolls the list options downward.	
	Long Press		
	Press	Performs no action.	
	Long Press	Saves any changes and returns user to the parent parameter screen.	

Keypad Functions from Warning Screen			
Button	Press Duration	Function	
	Press	Returns to the screen from which the warning screen was called.	
	Long Press	Clears all warnings and returns to the screen from which the warning screen was called.	
	Press	Scrolls the list of available warnings upward.	
	Long Press		
	Press	Scrolls the list of available warnings downward.	
	Long Press		
	Press	Displays the timestamp of warning in the active line at the time and date of occurrence.	
	Long Press		

Keypad Functions from Warning Details Screen			
Button	Press Duration	Function	
	Press	Returns to the warning screen.	
	Long Press	Clears the individual warning and returns to the warning screen.	
	Press	Performs no action.	
	Long Press		
	Press	Performs no action.	
	Long Press		
	Press	Performs no action.	
	Long Press		

**NOTE:** Some displays, calibrations and setup parameters are password protected. The proper password level must be used to gain access to password protected parameters.

## METER CHECKS

1. Confirm the flow sensor has been installed correctly.
2. Confirm the transmitter has been installed correctly.
3. Confirm all transmitter connections have been made correctly to the sensor.
4. Confirm the *Flow Factor* and *Density* calibration constants are the same on both the serial tags and calibration documents. See "Sensor Check" on page 49 for more information.
5. Familiarize yourself with the basic operation of the transmitter keypad.
6. Power up the transmitter. The display reads the current firmware version and does a self test.
7. Fill the flow sensor with fluid, passing the fluid through for at least ten minutes at a flow rate greater than twenty percent of the rated capacity of the meter.
8. Perform a zero calibration, see "Initial Zeroing Procedure" on page 50.

### Startup Screens

**NOTE:** Screens may differ depending on firmware version and enabled options.

1. Example of startup splash screen.




Figure 57: Splash screen

2. The transmitter is looking to see if there is a sensor connected. The Initializing text will display for one minute if no sensor is connected.




Figure 58: Transmitter initializing

3. If there is a sensor connected, the screen should look similar to this, if there is no flow and the meter is full of fluid.




Figure 59: Sensor connected—no flow

4. If there is fluid flow, the screen will look similar to this.




Figure 60: Sensor connected—with flow

5. If there is no sensor connected, the screen will change from *INITIALIZING* to *WARNING*.





Figure 61: No sensor warning screen

# MENU MAP



\*Hidden menus. Must be Enabled to view.

Figure 62: Menu map

## KEYBOARD LOCK

The optical buttons on the hazardous location RCTX transmitter may be locked to prevent accidental activation of the buttons. To unlock, press the Up arrow, Down arrow, Menu/Exit and Enter buttons sequentially, in a reverse "Z" pattern. See *Figure 63*. With each correct button press, two dark blocks appear at the bottom of the warning screen, beginning on the left. See *Figure 64*.

The Lockout function can be enabled or disabled through parameter *KbLock* (303).





Figure 63: Unlock keyboard



Indicates Correct Button was Pressed

Figure 64: Enter PIN code

## SYSTEM PASSWORDS

1. From the *Home* screen press **Menu** to enter the top level menus.
2. Use **Up** or **Down** to scroll until *SETUP* is in the active line of the display then press **Enter**.
3. From the *SETUP* prompt, press **Up** or **Down** until the display shows *Password*.

**NOTE:** In this menu, there are two parameters. *PWLvl* indicates the password level entered, if any. *PWSet* is the parameter used to change the password level.

4. To change to another password level, use **Up** or **Down** until *PWSet* is in the active line of the display, then press and hold **Enter**.
5. A cursor will appear under the first character of the password.
  - a. Using **Up** or **Down**, increment or decrement the value as needed.
  - b. To move the cursor to the next character space, press and hold **Up** to move the cursor to the right or press and hold **Down** to move the cursor to the left.
  - c. Follow this procedure to enter the required password PIN (personal identification number), then press and hold **Enter** to save the password.

### Default Passwords

The default system passwords PINs (personal identification numbers) are:

Engineer: 525  
 Technician: 604  
 Operator: 117

**NOTE:** Each higher password level inherits the capabilities of any passwords below it. To change the password PINs associated with each password level, see "*Changing a Password PIN*" on page 49.



## Changing a Password PIN

In the following instructions, Scroll means to press the **Up** or **Down** button. To change the default password pins for an additional level of security:

1. From the *Home* screen, press **Menu/Exit** to step into the top Main Menu structure.
2. Scroll through the menus until *SETUP* appears in the active line. Press **Enter**.
3. Scroll through the menu list until *PASSWORD* appears in the active line. Press **Enter**.
4. Scroll until parameter *PWSet* is in the active line. Press and hold **Enter** to initiate the editing function.
5. Enter the password pin for Engineer (525). (A short press of **Up** or **Down** changes the indicated character value. A long press of **Up** or **Down** moves the cursor to the right or left, respectively.) Press and hold **Enter** to save the change.
6. Press **Menu/Exit** to leave the *Password* menu, then step back into it. With *PASSWORD* in the active line, press **Enter**.

The available items in the password menu should now be *PWSet*, *PWLvl*, *Pr1*, *Pr2* and *Pr3*.

<b>PWSet</b>	Parameter used for entering password pins
<b>PWLvl</b>	Parameter showing which level of password is currently active in the transmitter
<b>Pr1</b>	Password Pin for Operator: Default (117)
<b>Pr2</b>	Password Pin for Technician: Default (604)
<b>Pr3</b>	Password Pin for Engineer: Default (525)

Table 3: Password menu parameters

To change the default pin associated with a particular password level:

7. Scroll until *Pr1*, *Pr2* or *Pr3* is on the active line, then press and hold **Enter** to begin the editing function.
8. The maximum pin length is 5 characters and can be numbers only. Use short presses of **Up** or **Down** to change the character value. Use long presses of **Up** or **Down** to move the cursor right and left, respectively. Press and hold **Enter** to save the change.

*Pr1*, *Pr2* and *Pr3* only change the pin for a particular password level. To make a particular password level active, you must enter the default or user-assigned pin in the *PWSet* parameter.

**NOTE:** Factory assistance is required to restore user-defined passwords.

## SENSOR CHECK

It is important to check that the sensor and transmitter are correctly matched. Unmatched sensor and transmitter pairs will produce inaccurate readings.

To check that the correct sensor has been connected to the correct transmitter, refer to the calibration documents that are sent with the meter system. The Flow Calibration Report includes vital information pertaining to the specific sensor and transmitter pair. Under "Product Information" there are fields for both sensor and transmitter model number and serial number.

Look at the outside of the sensor and transmitter and locate the serial tags. Pair the transmitter to the appropriate sensor by matching the serial numbers as indicated on the calibration report.

After the transmitter is powered on, make sure the calibration constants entered into the transmitter match the information provided on the serial tags and the calibration documents.

Flow Factor (FloFct): Main Menu > Set Up > Calibration > Flow

DAlpha: Main Menu > Set Up > Calibration > Density

DBeta: Main Menu > Set Up > Calibration > Density

If the numbers entered in the transmitter do not match what was provided on the serial tags and the calibration report, contact the factory for assistance.

## INITIAL ZEROING PROCEDURE

### Priming for Zero

This procedure requires a password level of Operator or higher.

The flow sensor must be completely full at stable process temperature and pressure before zeroing the system.

Even if the flow sensor has already been filled, circulate fluid for a minimum of 10 minutes at a flow rate greater than 20% of the rated full scale value of the flow sensor to purge both the process piping and sensor of air.

**NOTE:** Do not attempt the initial startup procedure with a partially filled sensor.

**NOTE:** If the process temperature or pressure changes significantly, the meter may need to be re-zeroed. If the meter is to be re-zeroed, make sure the meter is completely full and flow is shut off by first closing the downstream blocking valve and then the upstream blocking valve. This ensures there is no potential for cavitation in the sensor. Stopping the pump or relying on check valves does not ensure the zero flow condition necessary to perform the system zero.

### Zeroing the System

**NOTE:** The system must be zeroed after installation and before normal operation.

1. Run flow through the sensor at the highest possible rate for several minutes to eliminate any entrained gases in liquid systems.
2. Stop all flow and close the downstream and upstream blocking valves. Close the downstream valve first to prevent draining of the system.
3. From the *Home* screen, press **Menu** to enter into the Main Menu.
4. Press **Up** or **Down** to scroll through the list until *SETUP* appears in the active line, then press **Enter**.
5. Press **Up** or **Down** to scroll through the list until *CALIBRATION* appears in the active line, then press **Enter**.
6. Press **Up** or **Down** to scroll through the list until *ZERO CALIBRATION* appears in the active line, then press **Enter**.
7. Press **Up** or **Down** to scroll through the list until *START ZERO* appears in the active line.




Figure 65: Start zero screen

8. Press and hold **Enter** to initiate a zero calibration.
9. Press **Menu** until the top level menu screen is reached.
10. Press **Up** or **Down** to scroll through the list until *MEASUREMENT* is in the active line, then press **Enter**.
11. Press **Up** or **Down** to find the *mFlo* parameter. It should read all zeros.
12. Return to the *Home* screen. If there is a prompt to back up the transmitter, choose this action. If the prompt to back up the transmitter does not appear prior to getting to the *Home* screen, back up the transmitter manually.
13. Open the blocking valves. The meter is now ready to use.

## HOME SCREEN SETUP

RCT1000 transmitters feature a home screen to allow users to view whichever parameter is required to be in view at all times.




Figure 66: Home screen example

The RCT1000 has a four line display, but the *Home* screen holds eight parameters that are viewable at one time. Using **Up** or **Down**, users can view these parameters as this list scrolls and wraps around.

To set up the parameters for the *Home* screen:

1. From the *Home* screen, press **Menu** to step into the high level menus.
2. Using **Up** or **Down**, scroll through the list until *SETUP* appears in the active line and press **Enter**.
3. Using **Up** or **Down**, scroll until *DISPLAY* appears in the active line and press **Enter**.
4. Using **Up** or **Down**, scroll through the parameter list. Parameters are named *Param1*...*8*. These parameters correlate the order and ID for the parameters to be displayed on the *Home* screen. The parameter under *Param1* will be the default parameter listed on the first line of the *Home* screen, *Param2*...*8* follow suit.

**NOTE:** On the *Home* screen, use **Up** or **Down** to scroll through the available parameters.

Home screen Line 1	Param1	Home screen Line 5	Param5
Home screen Line 2	Param2	Home screen Line 6	Param6
Home screen Line 3	Param3	Home screen Line 7	Param7
Home screen Line 4	Param4	Home screen Line 8	Param8

Table 4: Home screen parameters

5. To edit which parameters are seen, place the required *Param1*...*8* in the active line and press and hold **Enter**.
6. Using **Up** or **Down**, scroll through the list of available parameters that can be seen on the *Home* screen.
7. Once a required parameter is seen, press and hold **Enter** to save the change. This parameter will now be listed to the line assigned on the *Home* screen.
8. After the required parameters to be viewed have been set, press **Menu** until the *Home* screen is reached.

### Enable/Disable Hidden Menus

1. From the *Home* screen, press **Menu** to enter the top level menus.
2. Using **Up** or **Down**, scroll through the list of available menus until *SETUP* is in the active line and press **Enter**.
3. Using **Up** or **Down**, scroll through the list of available menus until *MENUS* is in the active line and press **Enter**.
4. There are seven additional menus that can be enabled or disabled:
  - MnuBatch* (Batch Controller Menu)
  - MnuPID* (PID Controller Menu)
  - MnuTot* (Totalizer Menu)
  - MnuAlarm* (User Defined Alarm Menu)
  - MnuConc* (Concentration Menu)
  - MnuApp* (Special Application Menu)
  - MnuNet* (Net Flow Menu)
5. To enable or disable one of these menus, use **Up** or **Down** to scroll through the list and place the required menu to be *Enabled* or *Disabled* into the active line of the display.
6. Press and hold **Enter**.
7. Use **Up** or **Down** to scroll through the available options (*Show menu* or *Hide menu*).
8. To show the menu, select *Show menu*, then press and hold **Enter**. To hide the menu, select *Hide menu*, then press and hold **Enter**.

**NOTE:** Enabled/shown menus appear at the top level Main Menu structure.

## HMI EXAMPLES




Figure 67: Example of startup screen




Figure 68: Example of a command




Figure 69: Home screen or base parameter level within a menu

Figure 37 is also an example of parameters where units, resolution and value can be changed, password permitting.

**NOTE:** Measured or calculated values cannot be changed.



Figure 70: Example of transmitter being in menus or submenus




Figure 71: Example of parameters with enumerations

## EDITING PARAMETER UNITS, VALUES AND RESOLUTION

There are two ways to change the units, values and resolution associated with a parameter. It can either be done from the user defined *Home* screen or from stepping into the menus and changing the parameter at the bottom (parameter) level of the menu structure.

To change these items:

1. Scroll **Up** or **Down** until the required parameter is in the active line, then press and hold **Enter**.
2. The default item to be edited first is the value of the unit. Use **Up** or **Down** to change the value of the highlighted character. Press and hold **Up** to move the cursor to the right or press and hold **Down** to move the cursor to the left.
3. After changing the value, press **Enter**.
4. The next item to be edited is the unit of the parameter. Use **Up** or **Down** to scroll through the list of available units. Once the required unit appears, press **Enter**.
5. After step four, the next item to be changed is the resolution. This will appear in a **###** format. Use **Up** to increase the resolution or **Down** to decrease the resolution. The number of pound signs after the decimal indicates the resolution that will be set.
6. Press and hold **Enter** to save changes made to the parameter.

**NOTE:** Bypass any of the three edits by pressing **Enter**. The parameter will not save until you press and hold **Enter**.

**NOTE:** Not all parameters have values, resolutions or units associated with them. If an item is not available for the parameter, the item will not appear.

**NOTE:** Parameters with lists and no measured or calculated value with units, values and resolutions associated with them, still follow the same format for editing. Once the parameter is in edit mode, the list will appear and the user can scroll through the available list for the parameter. After the required one appears, press and hold **Enter** to save the parameter with the list item selected.

## BACKING UP THE TRANSMITTER

There are three ways to create backups:

- Automatically through flagged parameters.
- Manually through the HMI
- Through the RCT Console software

### Automatic Transmitter Backup

The automatic backup feature prompts you to initiate a backup. There are certain parameters within the transmitter that are flagged to create a backup if they are changed. These are parameters that have a significant impact on the configuration, whether it is a meter zero or a density factor. For a list of these parameters, see *"Backup Enabled Parameters" on page 54*.

Any time one of these is changed, it will signal the transmitter of the change. Once the user steps back out to the *Home* screen, prior to entering the *Home* screen, a prompt like this will appear. Follow the on-screen commands to either create or cancel the backup.



Figure 72: Parameter change triggered backup

### Manual Transmitter Backup

To create backups manually through the HMI:

1. From the *Home* screen, press **Menu** to enter the top level Main Menu.
2. Using **Up**, **Down** and **Enter**, navigate to the *SETUP > CALIBRATION > PRIMARY* menu.
3. Scroll **Up** or **Down** through the list of available parameters and place *BackUp* on the active line.
4. Press and hold **Enter** to bring the parameter into editing mode.
5. When in editing mode, a cursor will appear under the enumeration text shown to the right of the parameter name. Use **Up** or **Down** to switch the entry from *Idle* to *Backup* (see Figure 73).




Figure 73: Backup triggered from menu

6. Press and hold **Enter** to save the change and initiate the command. *WARNING* will appear on the bottom right of the display. This is a temporary indication a backup has been created.

### Transmitter Backup Using RCT Console Software

Refer to the RCT Console Help file for information on how to back up through the RCT Console.

## BACKUP ENABLED PARAMETERS

The following parameters, if altered, will cause the transmitter to prompt a backup request command.

Address	Parameter	Address	Parameter
5	Transmitter Serial	115	Brix A3
6	Sensor Serial	116	Brix B1
16	Sensor Size	117	Brix B2
20	Meter Zero	118	Brix B3
37	Application Menu Control	123	Current#1 Output Setup
39	Density Correction Temperature	124	Current#2 Output Setup
41	CPU Frequency Correction	125	Frequency #I Output Setup
44	Phase Correction	133	Pulse Width
46	Flow Factor	138	Batch Menu
47	Maximum Mass Flow Rate	158	PID Menu
48	Zero Mass Flow Limit	181	Brix C1
49	Mass Flow Temperature Factor	182	Brix C2
50	Mass Flow Linearization Factor	186	Driver Gain
51	RTD1 Linearization Offset	187	Driver Derivation Factor
52	RTD1 Linearization Slope	188	Driver Integrating Factor
66	Base Temperature	201	COM1 Protocol
72	Density Alpha	227	Analog 1 Slope
73	Density Beta	228	Analog 1 Offset
75	Density KT Factor	230	Current#3 Output Setup
76	Density OW Factor	232	Analog 2 Slope
79	Concentration Menu	233	Analog 2 Offset
87	Net Flow Menu	234	RTD2 Linearization Offset
88	Totalizer Menu	235	RTD2 Linearization Slope
89	Alarm Menu	260	COM2 Protocol
112	Brix Mode	261	MAINCPU Crystal Frequency
113	Brix A1	262	Voltage Reference
114	Brix A2	271	IFCPU Crystal Frequency

Table 5: Backup enabled parameters

## RESET TOTALS HELP

You can reset totals from two locations:

- Main Menu > Measurement
  - Main Menu > Totals
1. Move to the desired menu.
  2. Press the arrow keys to move **RESET TOTALS** to the active line.
  3. Press and hold **Enter** to reset totals.

## FLOW DIRECTION

If the fluid flow is reverse of the meter flow and reading negative flow when positive flow is desired, change the mass flow linearization factor *mLinFct* from 1 to -1. Changing this parameter requires the proper security level.

1. Navigate to *Main Menu > SETUP > CALIBRATION > FLOW*.
2. Scroll until *mLinFct* is the first line on the screen.
3. Press and hold **ENTER** to enter the editing mode.
4. Scroll down to change positive (+) to negative (-) and press **ENTER** to accept the change.
5. To exit the menus, press **MENU** at each new menu. A prompt to back up the parameters appears before exiting the Main Menu and returning to the Home Screen.

# OUTPUT CONFIGURATION

## Current Outputs

The RCTX transmitters have two current outputs plus a current output with HART (if the HART option is installed) that can send signals to peripheral devices (such as loop-powered remote indicators, controllers and similar equipment). These outputs may be independently set by the user, via software or keypad, for any range between 0...22 mA with 4...20 mA being the default. The maximum load (loop) impedance for each output is 500  $\Omega$ .

Normally the *IOut1* output is set for mass flow. However, this can represent other parameters. In these cases, the units of measure are (appropriately) different.

The *Main Menu* > *SETUP* > *SYSTEM IO* menu contains three current output channels:

- *CURRENT1 SETUP*
- *CURRENT2 SETUP*
- *CURRENT3 SETUP*

**NOTE:** Password level must be Technician or Engineer to change settings.

1. Enable the current output *EN*.
2. Assign the parameter to use with the current output *ID*.
3. Enter minimum current *IVluMn* and the minimum value of the assigned parameter *VluMn*.
4. Enter maximum current *IVluMx* and the maximum value of assigned parameter *VluMx*.

### Example

Parameter	Setting	Parameter	Setting
EN	Enable	—	—
ID	59, mFlo	—	—
IVluMn	4 mA	VluMn	100 lb/min
IVluMx	20 ma	VluMx	1000 lb/min

### Test Current

To test the current output:

1. In the current menu, set the test output (TstOut) to the desired current.
2. Check that the current output is enabled (EN).
3. Enable the test current for the specific current output:
 

HART Current Output 1	<b>+Alt1</b> (126)
Current Output 2	<b>+Alt2</b> (127)
Current Output 3	<b>+Alt3</b> (231)

### Monitor Current

The current for each of the outputs can be viewed:

HART Current Output 1	<b>IOut1</b> (120)
Current Output 2	<b>IOut2</b> (121)
Current Output 3	<b>IOut3</b> (229)

## Frequency, Pulse and PWM Outputs

The frequency channel has three modes. The first is straight frequency output in the range of 63...10,000 Hz with 3000 Hz being the typical maximum. The second is a pulse output (one pulse per every defined mass unit). The third is a pulse-width modulation (PWM) output that varies the ratio of on time to a set period. The output can be configured for one of the three modes.

The frequency channel can drive external devices such as rate indicators, batch totalizers and similar devices. Access the frequency setup parameters through the *Main Menu > SETUP > SYSTEM I/O > FREQUENCY SETUP* menu. Selecting *FREQUENCY SETUP* enters the frequency/pulse out menu.

**NOTE:** Password level must be Technician or Engineer to change settings.

1. Assign the parameter to the ID parameter.
2. Select output mode *PlsOM* (130).
  - ◇ Frequency
  - ◇ Pulse
  - ◇ PWM

### Frequency Output

1. From the *Frequency Output* menu, enable the pulse/frequency output *FrqOEN* (129) and *EN* (Enable).
2. Assign the parameter to use with the frequency output *ID*. The default is the mass flow rate *mFlo* (59).
3. Enter the *FrqMn* and the minimum value of the assigned parameter *VluMn*.
4. Enter the maximum frequency *FrqMx* and the maximum value of assigned parameter *VluMx*.

#### Test Frequency

To test the frequency output at a fixed value, set the output *TstOut* to the desired frequency and enable the test frequency *+AltFrq* (128). Check that *FrqOEN* and *EN* are enabled. While the test frequency is enabled, the warning message "6, Freq. out error" shows on the transmitter.

#### Monitor Frequency

To monitor the frequency output, view *FrqOut* (122).

### Pulse Output

1. From the *Frequency Output* menu, enable the pulse/frequency output *FrqOEN* (129) and *EN* (Enable).
2. Assign the parameter to use with the pulse output *PlsID* (131). The default is the mass totalizer *mTot* (80).
3. Enter total amount per pulse in *PlsSze* (132). The pulse width is fixed at 7 ms. Make sure that the pulse cannot trigger faster than every 14 ms for a 50% duty cycle at maximum flow rate.  
Example: Maximum mass flow rate is 600 lb/min or 10 lb/s, then the minimum pulse size is 0.14 lb.  
 $10 \text{ lb/s} * 0.014 \text{ s} = 0.14 \text{ lb}$

If the pulse size or mass totalizer is negative, a warning message shows on the transmitter.

- |                    |   |
|--------------------|---|
| 6, Freq. out error | Frequency output is enabled, but it is in test mode or has an invalid setting.<br>Test frequency <i>+AltFrq</i> (128) is enabled. Minimum frequency <i>FrqMn</i> is negative or minimum and maximum values are swapped. |
| 7, pulse out error | Assigned totalizer is negative or invalid pulse settings. Check the totalizer value and pulse size <i>PlsSze</i> (132) for a negative value.  |
| 34, FI low limit   | Value of measured parameter is below the minimum value <i>VluMn</i> .   |



## PID

RCT transmitters are also supplied with a built-in PID controller. This can be used for a large number of control applications, greatly simplifying the installation.

**NOTE:** Password level must be Technician or Engineer to change settings.

Parameter	Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
PSpt	151	PID Setpoint	X	X	X	X	X	X	X	X	X
PID EN	150	PID Enable/Disable	X	–		X	–		X	–	
PID ID	159	PID Parameter Identifier	X			X			X		–
POut	152	Output Percentage of PID Controller	X		X	X		X	X		X
SamTim	153	Sampling Time	X			X			X		–
PGn	154	PID Gain	X			X			X	X	
PDer	155	PID Derivative	X			X			X	X	
Plnt	156	PID Integer	X			X			X	X	
POfset	157	PID Offset	X	X		X			X	X	
PHold	259	PID Hold	X	–		X	–		X	–	

Table 6: PID menu parameters

### Modify the PID Control Settings

From the *Main Menu*, select **PID**.

If the *PID* menu is not listed in the menu, then enable it by selecting *SETUP > Menus > MnuPID*.

### PID Control Explanations

**PID output control variable (Pout):** Is the output of the PID in percentage.

$$Pout = Pout_{Previous} + PGn * Error + Plnt * \Sigma(Errors) + PDer * \Delta Error + POset$$

Where the Error = PSpt – (measured value of PID ID)

**Proportional (PGn):** Gives largest change in the output for a given change in error. When increased, decreases rise time and steady state error along with increasing the overshoot and changes the settling time by a little bit. As it is increased it also lowers the stability of the system.

**Integral (Plnt):** The integral takes into account both the magnitude and duration of the error to change the system. When increased, decreases rise time and eliminates steady state error however increases both the overshoot and the settling time. As with the proportional gain, as it is increased it lowers the stability of the system.

**Derivative (PDer):** The derivative attempts to predict system behavior and modify accordingly. When increased, decreases the overshoot and settling time along with delivering a minor changing the rise time and not affecting the steady-state error. Providing it stays relatively small, increasing will improve the stability of the system.

**Offset (POfset):** The offset value (in percentage) added to the PID control

**Process variable assignment (PID ID):** PID ID is the parameter of the process variable you want to measure. The process variable can be a direct measurement of the Coriolis meter (i.e. mFlo, Dens) or an external device wired to an analog input: AnIn1 or AnIn2.

PID		
Parameter	Factory Default	New Setting
PSpt	0	<set during operation >
PID EN	Disabled	Enabled
PID ID	59, mFlo	<user set >
SamTim	20 ms	<user set >
PGn	10	<user set >
PDer	-2	<user set >
Plnt	2	<user set >

## Enabling and Setting Values on the 4...20 mA Output Port

1. From the *Main Menu*, select *Setup > System I/O*.
2. To assign an analog current output to the PID control variable, set the ID of the *IOutput* to **Pout**, enable the IOutput and set the scaling parameters.

IOutput 1 (or IOutput 2 or IOutput 3)		
Parameter	Factory Default	New Setting
ID	59, mFlo	152, Pout
EN	Disabled	Enabled
IVluMn	4 mA	<user set >
IVluMx	20 mA	<user set >
VluMn	0	<user set >
VluMx	~1325 lb/min	<user set >
TstOut	0	<user set >

As an example for controlling a valve position in line with the Coriolis meter, the PID parameters were set at:

PID		
Parameter	Factory Default	New Setting
PSpt	0	<set during operation >
PID EN	Disabled	Enabled
PID ID	59, mFlo	59, mFlo
SamTime	20 ms	50 ms
PGn	10	2
PDer	-2	0.5
Pint	2	0.25

IOutput 1		
Parameter	Factory Default	New Setting
ID	59, mFlo	152, Pout
EN	Disabled	Enabled
IVluMn	4 mA	4 mA
IVluMx	20 mA	20 mA
VluMn	0	0
VluMx	~1325 lb/min	<max flowt >
TstOut	0	4 mA

## USER ALARMS

RCT transmitters include up to six user-defined alarms. The alarms can be programmed to trigger when process parameters exceed preset limits set by the operator.

Symbol	Default Setting	
Alarm-A	Mass flow alarm	mFlo
Alarm-B	Totalizer alarm	mTot
Alarm-C	Density alarm	Dens
Alarm-D	Temp. alarm	Temp 1
Alarm-E	PID alarm	POut
Alarm-F	Volumetric flow alarm	vTot

Table 7: User alarm menu

1. From the *Home* screen, press **Menu** to enter into the top level Main Menu. Using **Up** or **Down**, scroll until *ALARMS* is in the active line and press **Enter** to access the alarms menu.

**NOTE:** The alarms menu item *MnuAlarm* must be enabled for the alarms menu to be visible: See "*Enable/Disable Hidden Menus*" on page 51.

2. From the *Alarm* prompt, press **Up** or **Down** until the desired alarm (Alarm A...F) shows on the active line of the display.
3. Press **Enter** to access the specific alarm parameters list.
4. Use **Up** or **Down** to select the specific alarm parameter that is to be changed by placing it in the active line.
5. Press and hold **Enter** to edit the alarm parameter located in the active line. Use **Up** and **Down** to scroll through the alarm ID, to disable the alarm or change the values that trigger the alarm high and low limits.
6. To enable the alarm, scroll until *EN (x)* is in the active line. Press and hold **Enter** to edit parameter. Change the value from *Disable* to *Enable*.
7. Press and hold **Enter** to set the alarm.

Symbol	Description	Units
ID(x)	Alarm pointer item (A, B, C, D, E or F)	XXX (Parameter ID), (Parameter Name)
EN(x)	Enable or disable alarm (A, B, C, D, E or F)	Enable or Disable
XLo	Low limit	User assigned values of parameter that is assigned to that alarm.
XHi	High limit	

Table 8: Alarm variables

In addition to the high and low limits for each alarm, you can change the item that triggers the alarm. However, the message displayed when the alarm triggers remains as the default setting (see *Table 8*). When you go into the *Warning* screen to see alarm details, low/high flow will be shown. This message can be changed via the RCT Console.

### Example

If alarm A is set to work on tube frequency (*Freq*), then if the frequency increases above the preset value, the alarm triggers and *WARNING* is displayed.

Alarm outputs are normally connected to peripheral devices which are either resistive load devices or logic level sensing. Resistive load devices (in other words relays, indicator lamps, piezo alarms) are connected as shown in *Figure 45 on page 35 through Figure 51 on page 36*.

**NOTE:** These devices must have a minimum impedance of greater than 150  $\Omega$  or must be current limited to less than 100 mA maximum.

Logic load sensing devices, peripheral devices, PLCs or other TTL/CMOS compatible inputs should be connected as shown in *Figure 51*.

## COMMUNICATION WIRING AND SETUP

All RCT1000 transmitters include EIA-485 and USB programming ports.

**NOTE:** An RS485 Terminator resistor is provided for when end-of-line termination is required. The RCTX and RCTX with Display transmitters are shipped from factory with the shunt jumper in "Not Terminated" position.

### EIA-485 Port

The EIA-485 port is used for network connections and supports two protocol options: Modbus RTU and BMI Massmeter.

### USB Programming Port

The USB programming port is used for connecting a computer with RCT Console configuration and diagnostic software to the RCT transmitter. The USB programming port supports two protocol options: Modbus RTU and BMI Massmeter. RCT Console defaults to BMI Massmeter but can be changed to Modbus RTU if required. Both ports remain active while RCT Console is communicating with the transmitter through the USB port. The transmitter may not be able to respond to all requests if both the EIA-485 and USB programming ports are busy.

### EIA-485 / Modbus RTU

See "RCT1000 Modbus RTU Communication Protocol" user manual, available at [www.badgermeter.com](http://www.badgermeter.com).

### Optional HART Communication Card

See the "Coriolis Flow Meter HART Bidirectional Communication Protocol Data Access" user manual, available at [www.badgermeter.com](http://www.badgermeter.com).

### Optional Ethernet Communication Card

An optional Ethernet communication card can be ordered on the Coriolis transmitter by including the "E" designation in the Communication Protocol block in the part number construction. See "*Part Number Construction*" on page 66 for ordering information.

The Ethernet card supports both Modbus TCP/IP and EtherNet/IP protocols. Configuring the Ethernet IP address requires a computer with an Ethernet port.




Figure 74: Ethernet card

See "RCT1000 Modbus RTU Communication Protocol" user manual, "RCT1000 EtherNet/IP Communication Protocol" user manual and "RCT1000 Modbus TCP/IP Communication Protocol" user manual, available at [www.badgermeter.com](http://www.badgermeter.com).

## TROUBLESHOOTING

### Navigation During an Alarm Condition

When any sort of warning occurs, the keypad functionality changes—a momentary press of the **Menu/Back** button brings up the *Warnings* menu. At this time, you may feel you are stuck in a loop toggling back and forth between the Display and an alarm or warning.

To navigate to the Root list of menus, press and hold the **Menu/Back** button to move back in the directory.

This may be required in order to change the scaling of an output channel or to see what may be causing the alarm condition to occur.

Only during alarm or warning conditions will you need to use the long press function on the Menu/Back button to move back up the menu list. See *"Transmitter-to-Sensor Connections"* on page 37 for further details.

### WARNING Help

Any warning that appears on the transmitter will be erased from the screen once the problem has been fixed.

To clear WARNINGS:

1. Press **Menu** to bring up the *WARNINGS* window, which lists all current alarms and faults in the transmitter.
2. Press the arrow buttons to move the alarm or warning to the active line and press **Enter**.  
The display will prompt more information about the alarm or fault. It will display the time and date of the error.
3. To clear the warning, press and hold **Menu**. The screen will return to the menu related to the error.

**NOTE:** If the error is still present, the WARNING message will come back.

### WARNING

**DO NOT REMOVE OR REPLACE FUSE WHEN IT IS ENERGIZED.**

### Identifying System Faults

When a fault is suspected:

1. Identify the general symptom and, if possible, the fault type by referring to the tables in this section.
2. When the fault has been identified, run through the checks detailed to correct the problem.
3. Re-zero the system.

### Red/Green LED Diagnostics

The red and green LEDs located on the transmitter are basic diagnostic indicators. Blinking LEDs can indicate an alarm level that can be used to identify the type of error that has occurred. The LEDs for the RCTN are located under the cover on the rear left portion of the main PCB.

#### Startup

On power up, it is normal for the red LED to be on (solid) for a few seconds, then blink for up to a minute while the sensor stabilizes. Anytime the red LED is on, or blinking after one minute past power up, a sensor problem exists that requires further investigation.

#### Blink Code

The LEDs are ON/OFF blink coded according to the following logic:

- Neither LED on: check for power. The LED should always be on.
- Red LED solid: severe failure (level 7 and 8).
- Red LED blinking: high or low limit indicator, a level 1 or 2 warning indication, no effect to accurate measurement.
- Green LED solid: the startup drive hammer is engaged.
- Green LED blinking slow (blink 1/sec): normal sensor diagnostic, no flow.
- Green LED blinking fast: normal sensor diagnostic, flow > low flow cut off (or need to zero).

When first installed, the meter must be filled and zeroed. Before zeroing, the green LED may indicate a flow rate. After the zero process it should indicate no flow by blinking at the slow rate.

### **Indicated Error Levels**

Error levels 1 or 2 are high or low limit indications, such as one of the user settable alarm limits, one of the 4...20 mA limits or frequency output scaling limits is exceeded. Error levels 1...5 have no effect on accurate fluid measurement and totalization. Level 6...8 errors are more severe and accurate measurements cannot be achieved. Level 6...8 errors are:

- Measurement error (IFCPU)
- Tube frequency error
- RTD1 error
- No answer from IFCPU
- Sensor warning
- Driver overflow ( > 100%)
- Flash CSC is bad. Flash backup created during startup

## Error Messages

**NOTE:** Under certain conditions, multiple error/alarm conditions may exist. If alarms keep appearing, identify the message and keep taking corrective action until all messages cease.

Error Message	Alarm Level	Error Description	Possible Faults and Corrections
Code Error Xram Error EEPROM Error Back-up Error Back-up Recovered	7-8	Microprocessor program error, RAM error, EEPROM error or EEPROM back-up error. An internal hardware problem exists. This is NOT user programmable	If errors are intermittent but persistent, there may be a hardware problem on the CPU board. A <i>System Reset</i> may recover functional memory. If not, call the factory.
No Sensor Signal	6	Sensor errors caused by RTD circuit, sensor tubes resonance error (frequency out of programmed limits or no detector signal(s) from sensor).  Common causes are open/shorted sensor coils, sensor wiring, defective interface or driver cards or incorrectly programmed frequency limits.	No feedback from the sensing coils ( <i>CoilA</i> and <i>CoilB</i> are less than 19 mV). The problem could be a bad drive coil, sensor wiring or defective driver or interface card.
Sensor Warning			Driver set point error. Sensor voltage outside of driver set point ( <i>DrvSpt</i> ) by $\pm 5\%$ .
Resonance Error			Tube resonance limits (70...200 Hz) are being exceeded. Sensor operating frequency exceeds <i>MxFreq</i> or is less than <i>MnFreq</i> .
Temp. Error			Temperature (RTD) measurement error. Problem could be sensor wiring, control/relay card problem or processor (CPU) card.
HW Limit IOut1 HW Limit IOut2 HW Limit IOut3 HW Limit on Freq.	5	Hardware limits exceeded on output channels, or attempt to zero the unit with flow present. These items are not user programmable, as they are functions of the hardware.	The computed output exceeds hardware limits. For example, if the HW limits on Freq analog channels are set to 0...20 mA and the channel is scaled to 0...100 lb/min on current channel two, if the flow is 105 lb/min, the computed output will exceed the programmed limit. In this case, <i>HW Limit IOut2</i> will be displayed.
IOut1 High/Low Limit IOut2 High/Low Limit IOut3 High/Low Limit Freq High/Low Limit	4	Software limits (set points) on the analog and frequency output channels are being exceeded.	The computed output is below the programmed low limit or above the programmed high limit. For Example, if the upper span of the frequency was set to 1000 Hz at 1000 lb/min and the low end was 1015 lb/min the "Freq. High Limit" alarm would be displayed. If the flow was 90 lb/min, the "Freq. Low Limit" would be displayed.
Cntr. High/Low Limit	4	PID output limits are being exceeded.	The computed output of the PID is greater than 100% (high alarm) or under 0% (low alarm).
Answer Error	3	Master/slave communication error on the serial communications port. These types of errors are only associated with serial communications. These errors would normally indicate a hardware or software failure in the host device.	The "master" unit transmitted to the "slave" unit, but received a message with an error in transmission or no answer was given.
Master Time-Out			The "master" unit transmitted to the "slave" unit, but received no reply.
Master Duplex			The "master" unit transmitted to the "slave" unit, but received a reply before it was ready.
COM-Duplex	2	Communication errors on the serial port. Serial port alarms turn on Opto #1, but are NOT user programmable. These alarms normally indicate a hardware problem in an external device.	A message was received in transmitting.
COM-Command			An error in the command field.
COM-Bad ID			An error in the ID field.
COM-Bad Unit			An error in the units field.
COM-Long Message			The received message was too long.
COM-Short Message			The received message was too short.
COM-Bad Conv			The floating point conversion was incorrectly formatted.
COM-Bad Overrun			The character buffer over-ran or the baud rate may be wrong.
COM-Timeout			Make sure connection, baud rates and addresses are correct.
COM-Bad SOH			
High/Low Flow High/Low Total High/Low Density High/Low Batch High/Low Temperature High/Low Alarm Limit	1	High and low limits for user defined alarms have been exceeded.	These alarms are user programmable with Opto #2 becoming active. The user may set the level(s) of data that would trigger the high or low alarm. For example, a batch alarm could be "tied" to the current batch amount, <i>BTot</i> , such that if a batch set point, <i>BSpt</i> , exceeding a receiving tanks capacity was entered, Opto #2 would activate (after <i>BTot</i> was exceeded highlighting the potential problem).
Zero Flow Error		The zero offset exceeds the low flow cutoff.	Make sure the sensor is full of fluid and that there is no flow. Set <i>ZroL</i> to 5%. Try to zero the meter again. Reset <i>ZroL</i> to 1% after a successful zero.

Table 9: Error messages

## Troubleshooting Symptoms

Symptom	Possible Cause	Recommended Action
<b>Transmitter appears to not power up</b>	<b>Inadequate or no power Blown fuse</b>	Confirm power is available to the transmitter.
		Measure voltage at the power terminals and check that the voltage matches the labels by the power terminals.
		Check that the power terminal block is firmly seated.
		For AC power, verify that the 115V/230V switch is in the correct position.
		Check the fuse near the power terminals. If fuse is blown, verify the voltage and polarity is correct and replace the fuse.
		Check that at least one LED on the main board is lit. If no LEDs are lit and the above actions are completed, replace the transmitter.
		Check that the ribbon cable from the main board to the keypad/display is firmly seated.
		Cycle power to the transmitter.
		Replace the transmitter if following the above actions does not resolve the issue.
<b>Mass flow reading appears to be too high or too low</b>	<b>Installation issues Process issues Improper zeroing of the meter Incorrect parameter settings</b>	Check the installation of the sensor according to installation instructions.
		Run HealthTrack, the advanced function in RCT Console configuration software, to record critical measurements. Multiple, vital parameters can be viewed in a single snap-shot to assist with diagnosing issues.
		Check for mechanical vibrations or process loop instability. The impact of vibrations might be visible in the parameter.
		<ul style="list-style-type: none"> <li>System &gt; Sensor &gt; <i>CoilAv</i> should be 60 mV (<math>\pm 3</math> mV).</li> <li>Isolate the meter from the mechanical vibration.</li> </ul>
		Check process loop for entrained air which will impact the mass flow.
		Check that there is no air in the sensor when zeroing the meter. Make sure that flow has completely stopped and all blocking valves are closed. Re-zero the meter.
		Verify that the calibration factors on the sensor are entered correctly to the transmitter.
		<ul style="list-style-type: none"> <li>Set Up &gt; Calibration &gt; Flow &gt; <i>FloFct</i> (Flow Factor)</li> <li>Set Up &gt; Calibration &gt; Density parameters: <i>DAlpha</i> and <i>DBeta</i></li> </ul>
<b>Abnormal or Incorrect Mass Flow Readings</b>	<b>Installation issues Flow instability</b>	Run HealthTrack, the advanced function in RCT Console configuration software, to record critical measurements. Multiple, vital parameters can be viewed in a single snap-shot to assist with diagnosing issues.
		Check for mechanical vibrations. Impact of mechanical vibrations might be visible in the parameters.
		System > Sensor > <i>DrvOut</i> and <i>Freq</i> (tube frequency) readings. <i>DrvOut</i> should be between 10...95% and <i>Freq</i> should be between:
		<ul style="list-style-type: none"> <li>90...115 Hz (RCS005)</li> <li>170...220 Hz (RCS008)</li> <li>80...110 Hz (RCS018...050)</li> <li>40...90 Hz (RCS100...300)</li> </ul>
		The frequency stability should be better than $\pm 0.01$ Hz for a good measurement.
		Isolate the meter from the mechanical vibration.
		Another cause of instability is excessive flow rate. The flow shouldn't exceed 100% of the rating of the meter. Under <i>Main Menu</i> > <i>MEASUREMENT</i> , check parameter <i>%mFlo</i> . If the value is greater than 100%, the process is exceeding the max flow rate of the meter.
		Check process loop for variations of entrained air which will impact the mass flow.
		Check for pump induced flow instability.
		Modify <i>Mass Flow Dampening</i> parameter to adjust the filtering.
		Set Up > Calibration > Flow > <i>mDmp</i> can be adjusted from 1...99%.



Symptom	Possible Cause	Recommended Action
Density reading appears to be incorrect	Installation issues Process loop issues Incorrect parameter settings	Check process loop for entrained air and concentration of mix fluids which will impact the density.
		Run HealthTrack, the advanced function in RCT Console configuration software, to record critical measurements. Multiple, vital parameters can be viewed in a single snapshot to assist with diagnosing issues.
		Check for mechanical vibrations. Impact of mechanical vibrations might be visible in the parameters.
		System > Sensor > <i>DrvOut</i> and <i>Freq</i> (tube frequency) readings. <i>DrvOut</i> should be between 10...95% and <i>Freq</i> should be between: <ul style="list-style-type: none"> <li>90...115 Hz (RCS005)</li> <li>170...220 Hz (RCS008)</li> <li>80...110 Hz (RCS018...050)</li> <li>40...90 Hz (RCS100...300)</li> </ul> <b>NOTE:</b> The frequency stability should be better than $\pm 0.01$ Hz for a good measurement
		Verify that the calibration factors on the sensor are entered correctly to the transmitter: <ul style="list-style-type: none"> <li>Set Up &gt; Calibration &gt; Flow &gt; <i>FloFct</i> (Flow Factor)</li> <li>Set Up &gt; Calibration &gt; Density parameters: <i>DAAlpha</i> and <i>DBeta</i></li> </ul>
Volumetric flow reading appears to be incorrect	Mass or density readings are incorrect	Volumetric flow rate is calculated the mass flow rate divided by the density: $vFlo = mFlo/Dens$
Sensor temperature (Temp1) reading appears to be incorrect	Incorrect wiring Cable issue RTD not functioning	Verify sensor RTD is properly wired to transmitter (pins 2, 3 and 4).
		At the transmitter, disconnect the sensor wiring. Measure the resistance between brown and yellow/gray sensor wires. The resistance should be approximately 110 Ohms at 77° F (25° C). The resistance will vary depending on the fluid temperature. The resistance between the yellow and gray sensor wires should be less than 5 Ohms.
		If there appears to be an open or short at the transmitter end of the cable, remove the sensor cable from the sensor and measure the resistance from pin J to pins G/H on the sensor. The resistance should be 80...100 Ohms for temperatures less than 32° F (0° C) and 100...180 for temperatures greater than 32° F (0° C). Depending on the fluid temperature, the resistance between pins G and H should be less than 1 Ohm.
		Check the RTD Calibration constants in <i>Set Up &gt; Calibration &gt; Temperature</i> . <i>RTD1Of</i> should be 0 ( $\pm 5$ ). <i>RTD1SI</i> should be 1.00 ( $\pm 0.1$ ).
		If there appears to be an open or short at the pins, replace the sensor.
Current, frequency, pulse or PWM outputs do not match the readings	Incorrect parameter settings Wiring configuration issues Control system configuration issues	If the sensor measurements are in the acceptable range, replace the sensor cable.
		See " <i>Output Configuration</i> " on page 32 for parameter settings.
		Check that the ID parameter for the output matches the parameter of the desired reading.
		Verify that the minimum and maximum parameters for the output are set properly.
		Verify the device reading the output is set up correctly. The current and frequency outputs have a test output ( <i>TstOut</i> ) that can be used to troubleshoot system issues.

Table 10: Troubleshooting symptoms/resolution

		□	□	-	□	-	□	-	□	-	□	□	-	□	-	□
<b>Model</b>																
Badger Meter Coriolis Flow Meter		RCS														
<b>Nominal Line and Equivalent Pipe Size</b>																
1/4 in., 1/16 in.		005														
1/4 in., 3/32 in.		008														
<b>Wetted Material</b>																
316L Stainless Steel		S														
<b>Process Connection Type</b>																
NPT		NPT														
O-Ring, Face Sealing Body, 9/16-18 Threads		FSM														
O-Ring, Face Sealing Gland		FSF														
<b>Electronic Mounting Options</b>																
Remote Mount Transmitter		R														
<b>Certifications</b>																
General/Ordinary Area		G														
<b>Calibration/Meter Uncertainty</b>																
Liquids (Gases)																
Mass Flow: 0.1% (0.5%) ± 0.05% of FS zero stability; Density: ± 0.002 g/cm3		3														
<b>Reserved</b>																
None (Reserved)		N														
<b>Specials</b>																
Special Code (leave blank for non-custom orders)		XXX														

## Sensor Part Number (Remote Mount Transmitter Option)

<b>Model</b>																	
Badger Meter Coriolis Flow Meter		RCS															
<b>Nominal Line and Equivalent Pipe Size</b>																	
1/2 in., 3/16 in. (4.76 mm)		018															
1/2 in., 1/4 in. (6.35 mm)		025															
1/2 in., 1/2 in. (12.70 mm)		050															
1 in., 1 in. (25.40 mm)		100															
2 in., 2 in. (50.80 mm)		200															
3 in., 3 in. (76.20 mm)		300															
<b>Wetted Material</b>																	
316L Stainless Steel		S															
<b>Process Connection Type <sup>1</sup></b>																	
NPT (018...200 sensors only)																	
Class 150 ASME B16.5 Flange (018...300 sensors only)																	
Class 300 ASME B16.5 Flange (018...300 sensors only)																	
Class 600 ASME B16.5 Flange (018...300 sensors only)																	
PN40 Flange																	
Tri-clamp																	
<b>Electronic Mounting Options</b>																	
Remote Mount Transmitter																	
<b>Certifications</b>																	
General/Ordinary Area, CE																	
cCSAus Class I, Div 1; Class I, Zone 0																	
ATEX I.S. Zone 0 sensor, CE																	
IECEX I.S. Zone 0 sensor																	
ATEX/IECEX I.S. Zone 0 sensor, CE																	
<b>Calibration/Meter Uncertainty Liquids</b>																	
Mass Flow: 0.1% of reading $\pm$ 0.025% of full scale (100, 200, 300 sensors only)																	
Mass Flow: 0.2% of reading $\pm$ 0.05% of full scale (018...050 sensors only)																	
Mass Flow: 0.1% of reading																	
API Volumetric Flow: $\pm$ 0.01% of reading with 3rd party calibration (RCS200 only) <sup>2</sup>																	
<b>Pressure Registration</b>																	
CRN for Canada (Process connection types NPT, FAA, FAB only)																	
None																	

<sup>1</sup>Other process connection types can be provided. Consult factory for pricing and delivery estimates.<sup>2</sup>Includes volumetric calibration with oil equivalent API Ch 4.8, 5.6, 12.2.3

General Safety Transmitter Part Number (Remote Mount)

RCTN

-

K

-

D2R

-

-

Power

24V DC, 115/230V AC (preset for 115V)

D2

24V DC, 115/230V AC (preset for 230V)

G2

Communication Protocol

Modbus RTU & Ethernet (Modbus TCP/IP, EtherNet/IP)

E

Modbus RTU (Standard on all models)

M

Sensor Connection

Ordinary Areas (RCTN only)

N

Hazardous Location Transmitter Part Number (Remote Mount)

RCTX

-

K

-

R

-

-

Certifications

cCSAus Class I, Div 1; Class I

H1

Zone 1 ATEX I.S. Zone 1

A1

IECEX I.S. Zone 1

C1

ATEX/IECEX Zone 1

Y1

Communication Protocol

Modbus RTU & Ethernet (Modbus TCP/IP, EtherNet/IP)

E

Modbus RTU (Standard on all models)

M

Modbus RTU & HART

H

Sensor Connection

Hazardous location (RCTX only)

B



## SPECIFICATIONS

### System with RCS005/RCS008 Sensors

Uncertainty	Mass Flow Rate (Liquids)	RCS005	± 0.1% for flow rate > 0.05 lb/min ± 0.00005 lb/min for flow rate <= 0.05 lb/min
		RCS008	± 0.1% for flow rate > 0.2 lb/min ± 0.0002 lb/min for flow rate <= 0.2 lb/min
Density	±0.12486 lb/ft³ (0.002 g/cm³)		
Repeatability	±0.05% of reading ± zero stability		
Zero Stability	RCS005	±0.00005 lb/min	
	RCS008	± 0.0002 lb/min	
Safety Certifications	Ordinary Location	UL61010–1/CSA C22.2 No. 61010–1:2010	
Density Measurement	Flowing, referenced, API, Brix, Baume and net oil		
Conformance	CE		

### Flow Rate Specifications

Model	Nominal Line and Equivalent Pipe Size	Number of Flow Tubes	Flow Range		Volumetric Equivalent 1 g/cm <sup>3</sup>	
			lb/min	kg/hr	gal/min	l/h
RCS005	1/4 in., 1/16 in.	1	0...1.25	0...34	0.124	34
RCS008	1/4 in., 3/32 in.	1	0...2.75	0...74.8	0.274	74.8

### RCS005/RCS008 Sensors Specifications

<b>Pressure</b>	<b>Model</b>	<b>Maximum Allowable Pressure</b>
	RCS005	2755 psi (190 bar)
	RCS008	1800 psi (124 bar)
<b>Wetted Materials</b>	<b>Standard</b>	316L stainless steel
<b>Temperature</b>	<b>Fluid Range</b>	–40...392° F (–40...200° C)
	<b>Accuracy</b>	±1.8° F (1° C)
	<b>Repeatability</b>	±0.54° F (0.3° C)
<b>Process Connections</b>	1/4 in. O-ring face sealing	
<b>Conformance</b>	ASME B31.3 Pressure Piping Hydro Test NACE MR0175/ISO 15156	

The complete remote mount metering system consists of the following; each component must be purchased separately:

- Sensor
- Transmitter
- Cable assembly

## System Specifications

<b>Uncertainty</b>	Mass Flow Rate (Liquids)	RCS018, RCS025, RCS050 (option 2)	±0.2% of reading ±0.05% of full scale
		RCS100, RCS200, RCS300 (option 1)	±0.1% of reading ±0.025% of full scale
		RCS018...300 (option 6)	±0.1% of reading*
<b>Density</b>	RCS018, RCS025, RCS050	±0.12486 lb/ft <sup>3</sup> (0.002 g/cm <sup>3</sup> )	
	RCS100, RCS200, RCS300	±0.03121 lb/ft <sup>3</sup> (0.0005 g/cm <sup>3</sup> )	
<b>Repeatability</b>	RCS018, RCS025, RCS050, RCS100, RCS200, RCS300	±0.05% of reading ± zero stability	
<b>Zero Stability</b>	RCS018, RCS025, RCS050	±0.05% of full scale	
	RCS100, RCS200, RCS300 (option 1)	±0.025% of full scale	
	RCS100 (option 6)	±0.123 lb/min (3.35 kg/hr)	
	RCS200 (option 6)	±0.360 lb/min (9.79 kg/hr)	
	RCS300 (option 6)	±0.356 lb/min (9.68 kg/hr)	
<b>Safety Certifications</b>	Ordinary Location	Remote mount	CAN/CSA C22.2 No. 61010-1-12
		Integral mount	CI I, Zn 1 AEx/Ex db ia IIB T4 Gb Explosion-proof for CI I Div 1 Grp CD with Intrinsically Safe Sensor for CI I Div 1 Grp CD
		Remote transmitter	CI I, Zn 1 AEx/Ex db [ia Ga] IIB T6...T3 Gb Explosion-proof for CI I Div 1 Grp CD
		Remote sensor	CI I, Zn 0 AEx/Ex ia IIB T6...T3 Ga Intrinsically Safe for CI I Div 1 Grp CD
	ATEX / IECEx	Integral mount	II 2 G Ex db ia IIB T4 Gb
		Remote transmitter	II 2 (1) G Ex db [ia Ga] IIB T6...T3 Gb
		Remote sensor	II 1 G Ex ia IIB T6...T3 Ga
<b>Density Measurement</b>	Flowing, referenced, API, Brix, Baume and net oil		

\* When flow rate is less than zero stability (lb/min) \* 1000, accuracy = zero stability / flow rate.

## Flow Rate Specifications

Model	Nominal Line and Equivalent Pipe Size	Number of Flow Tubes	Flow Range		Volumetric Equivalent 1g/cm <sup>3</sup>	
			lb/min	kg/hr	gal/min	l/h
RCS018	1/2 in., 3/16 in.	2	0...20	0...544	2.4	544
RCS025	1/2 in., 1/4 in.	2	0...40	0...1088	4.8	1088
RCS050	1/2 in., 1/2 in.	2	0...220	0...5987	26	5987
RCS100	1 in.	2	0...1000	0...27,216	120	27,716
RCS200	2 in.	2	0...1700	0...46,266	204	46,266
RCS300	3 in.	2	0...5200	0...141,520	623	141,520

## Sensor Specifications



Sensor Specifications		Maximum Allowable Pressure (by Connection Type)				
Pressure	Model	NPT	Class 150 Flange	Class 300 Flange	DN PN40	Tri-Clamp
	RCS018	3450 psi (238 bar)	275 psi (19 bar)	720 psi (49.6 bar)	40 bar (580 psi)	200 psi (14 bar)
	RCS025	3450 psi (238 bar)	275 psi (19 bar)	720 psi (49.6 bar)	40 bar (580 psi)	200 psi (14 bar)
	RCS050	3320 psi (229 bar)	275 psi (19 bar)	720 psi (49.6 bar)	40 bar (580 psi)	200 psi (14 bar)
	RCS100	2150 psi (148 bar)	275 psi (19 bar)	720 psi (49.6 bar)	40 bar (580 psi)	200 psi (14 bar)
	RCS200	2200 psi (152 bar)	275 psi (19 bar)	720 psi (49.6 bar)	40 bar (580 psi)	200 psi (14 bar)
	RCS300	—	275 psi (19 bar)	720 psi (49.6 bar)	40 bar (580 psi)	200 psi (14 bar)
Wetted Materials	Standard	316L stainless steel				
Temperature	Fluid Range	General Safety: -40...392° F (-40...200° C) Hazardous Location Sensor with Integral Mount Transmitter: -4...140° F (-20...60° C) Hazardous Location Sensor with Remote Mount Transmitter: -4...359° F (-20...182° C) as follows:				
		TEMP CODE		FLUID TEMP (MAX)		
		T6 (85° C)		67° C		
		T5 (100° C)		82° C		
		T4 (135° C)		117° C		
	T3 (200° C)		182° C			
Accuracy	±1.8° F (1° C)					
Repeatability	±0.54° F (0.3° C)					
Process Connections	NPT (RCS018...200), Class 150 Flange, Class 300 Flange, DN PN40, Tri-Clamp					
Conformance	NACE MR0175/ISO 15156					
Pressure Standards/ Approvals	Canadian Registration Number (CRN); ATEX and general area sensors: PED 2014/68/EU, Group 1, Category II, Module D1 for line sizes 2 in. (60.3mm) and up, and Sound Engineering Practice (SEP) for other sizes					

## Transmitters

Feature		Model		
		RCTN	RCTX	RCTX with Display
Enclosure		NEMA 4 (IP65); powder coated aluminum, polycarbonate, urethane and stainless steel	NEMA 4X (IP66); powder coated aluminum, polycarbonate, urethane and stainless steel without glass window	NEMA 4X (IP66); powder coated aluminum, polycarbonate, urethane and stainless steel with glass window
Power Requirements		115/230V AC; ±15% 50/60 Hz 25W maximum	—	—
		20...28V DC; 15W maximum	18...28V DC; 15W maximum	
Ambient Temperature		14...158° F (–10...70° C)	– 4...140° F (–20...60° C)	– 4...140° F (–20...60° C)
Configuration		Four–button HMI or RCT Console configuration	RCT Console configuration	Four–Optical button HMI or RCT Console configuration
Display		4 line × 20 character; alpha-numeric; dot matrix; LED backlighting	—	4 line × 20 character; alpha-numeric; dot matrix; LED backlighting
RTD Input	Standard (1 input)	Built–in 100 Ohm Platinum RTD within the sensor body		
	Optional (1 auxiliary input)	Additional 100 Ohm 3–wire Platinum RTD input for the secondary RTD is used by customers who want to be able to calibrate their RTD	—	—
Analog I/O	Outputs	Three 4...20 mA (0...22 mA capable), maximum load 500 Ohms, approximately 16 bit resolution outputs; assignable to mass flow, volume, density, temperature, concentration, PID and similar measurements. User defined fault condition output value anywhere in the 0...22 mA range	Two (three with HART Option) 4...20 mA (0...22 mA capable), maximum load 500 Ohms, approximately 16 bit resolution outputs; assignable to mass flow, volume, density, temperature, concentration, PID and similar measurements. User defined fault condition output value anywhere in the 0...22 mA range	
	Inputs	Two 0...5V DC inputs. 20k Ohms input impedance, approximately 12 bit resolution	One 0...5V DC input. 20k Ohms input impedance, approximately 12 bit resolution	
Auxiliary Power		Internal 24V DC supply, 100 mA max. (for batching functions, frequency output channel and like applications)	—	—
Frequency/Pulse Output		One open collector transistor, user configurable as rate (3 kHz max output), accumulator 0...10 Hz; PWM with 1 kHz, 5...28V DC carrier. User assignable to rate, any totalizer, PID, temperature, density, concentration or other similar measurements		
Digital I/O	Outputs	Four 5...28V DC, 50 mA maximum current draw (external pullup resistor required)	Two 5...28V DC, 50 mA maximum current draw (external pullup resistor required)	
	Inputs	Four 5...24V DC, 1k Ohms impedance	Three 5...24V DC, 1k Ohm impedance	
Industrial Communications Modular Port	Standard	Modbus RTU (EIA–485/RS485)		
	Optional Module	Modbus TCP/IP & EtherNet/IP		
	Optional Module	—	HART 7	
Standard Configuration Port		USB 2.0 interface (through a Mini–B receptacle) for RCT Console software		
Alarms		Six Hi/Lo Alarms; Alarm status on display by default, assignable to digital Output 2 or 4 and available via digital communications	Six Hi/Lo Alarms; Alarm status on display by default, assignable to digital Output 2 and available via digital communications	
Transmission Distance		Up to 100 ft (30 meters); contact factory if longer length is needed		
Measurements		Forward and reverse mass flow and total, density, temperature; concentration, volumetric flow and total (derived)		
Other Functions		Batch control, PID control. User configuration of all I/O functions		



## CABLE KITS

The kits include the cable assembly, cable protector and sensor cable connection cover.			
<b>RC820476-XX</b>	Kit, PVC jacketed cable <b>XX</b> =length in ft; 20, 35, 50, 70, 100	Temp range: -40...176° F (-40...80° C)	 <p>General Safety Kit</p>
<b>RC820477-XX</b>	Kit, FEP jacketed cable <b>XX</b> =length in ft; 20, 35, 50, 70, 100	Temp range: -94...392° F (-70...200° C)	
<b>RC830054-XX</b>	TFE jacketed cable <b>XX</b> =length in ft; 20, 35, 50, 70, 100	Temp range: -4...140° F (-20...60° C)	 <p>Hazardous Location Cable</p>

## PARAMETERS BY ADDRESS (ADDR)

Addr	Symbol	Data Type	Parameter Name	Parameter Description
0	SDate	String	Software Date	Date of transmitter software
1	ComAdd	Byte	Comm Address	Communication address
2	BaudRate	Float	Baud Rate	Baud rate of transmitter
3	FWV	String	Software Version	Version number of transmitter firmware
4	SMT	String	Sensor Type	Type of installed sensor
5	Ntwk#	String	Transmitter Serial	Serial number of transmitter
6	Sen#	String	Sensor Serial	Serial number of sensor
7	Reset	Byte	Reset Transmitter	Resets transmitter
9	Contrast	Float	Display Contrast	Sets contrast of display
10	strtB	Byte	Start Bits	State of start bits
11	Status	Byte	Status Bits	State of status bits
12	StopB	Byte	Stop Bits	State of stop bits
13	AlmStat	Byte	Error Record	(Error record)
14	InSts	Byte	Status Inputs	State of status input bits
15	OutSts	Byte	Status Outputs	State of status output bits
16	SenSize	Byte	Sensor Size	List of available sensors
17	Key	Byte	Keyboard Code	Code of last pressed key
20	Zero	Float	Meter Zero	Measured phase when no flow
21	—	Byte	Start Zero Calibration	Starts zero calibration
22	—	Byte	Stop Zero Calibration	Stops zero calibration
23	ZroAvg	Float	Average Meter Zero	Average phase during zeroing
24	SenWL	Float	Sensor Warning Limit	Sensor level warning limit
25	ZroRng	Float	Meter Zero Range	Zero range during zero calibration
26	ZroTFac	Float	Meter Zero Temperature Correction	Temperature correction of meter zero value
28	ZroCntr	Byte	Zero Calibration Counter	Progress counter of zero calibration
29	ZroL	Float	Zero Calibration Start Limit	Flow rate must be less than this percentage of full scale to start zero calibration
30	IPhase	Float	Raw Phase	Unfiltered phase difference
31	TotWCnt	Unsigned Integer	Totalizer Wrap Count	Counts how many times the totalizer has been wrapped around
32	BatSus	Byte	Suspend Batch	Suspends batching while = 1
33	Phase	Float	Phase	Filtered phase difference
35	PhsCrt	String	Critical Phase	Critical phase
36	PhsSlp	Float	Critical Phase Slope	Critical phase slope
37	MnuApp	Byte	Application Menu Control	Turns ON or OFF the application menu
38	SenMat	Byte	Sensor Material	Material the sensor is made of
39	DTCrt	Float	Density Correction Temperature	Temperature coefficient for normalizing frequency dependence on temperature
40	PhsFil	Byte	Phase Filter	Length of the phase filtering ring buffer
41	CPUCrt	Float	CPU Frequency Correction	Correction factor to normalize CPU clock error
42	ERHist	Error Record	Error History	Error history record of transmitter
43	+RFlow	Byte	Enable Reverse Flow	Enables/disables the reverse flow calculation
44	PhsNor	Float	Phase Correction	Phase normalization
45	IFlow	Float	Raw Mass Flow Rate	Non-filtered mass flow rate
46	FloFct	Float	Flow Factor	Mass flow factor
47	MxFlo	Float	Maximum Mass Flow Rate	Nominal maximum mass flow rate anticipated in the meter
48	MnFlo	Float	Zero Mass Flow Limit	If the mass flow rate less than this limit, the flow will read as zero
49	mTFct	Float	Mass Flow Temperature Factor	Compensation factor of mass flow rate
50	mLinFct	Float	Mass Flow Linearization Factor	Linearization factor of the mass flow rate
51	RTD1Of	Float	RTD1 Linearization Offset	Offset linearization factor of the Pt-100 sensor
52	RTD1SI	Float	RTD1 Linearization Slope	Slope linearization factor of the Pt-100 sensor
53	DCrt	Float	Density Correction Factor	Density correction factor of mass flow
54	mDmp	Byte	Mass Flow Dampening	Filter number for mass flow rate
55	RemFlo	Float	Reverse Mass Flow Rate	Reverse mass flow rate (not implemented yet)
56	NetFlo	Float	Net Mass Flow Rate	Net mass flow rate

Addr	Symbol	Data Type	Parameter Name	Parameter Description
57	NetVFlo	Float	Net Volumetric Flow Rate	Net volumetric flow rate
58	%mFlo	Float	Percentage Mass Flow	Mass flow in percentage of maximum mass flow rate
59	mFlo	Float	Mass Flow Rate	Filtered mass flow rate
60	Freq	Float	Tube Frequency	Vibration frequency of sensor tubes
61	CycT	Float	Cycle Time of Main CPU	Cycle time of main CPU
62	MnFreq	Float	Minimum Tube Frequency	Minimum vibration frequency of sensor tubes
63	MxFreq	Float	Maximum Tube Frequency	Maximum vibration frequency of sensor tubes
64	Zrom	Float	Meter Zero in Mass Flow Rate	Meter zero of the sensor expressed in mass flow units
65	Temp1	Float	Temperature #1	Temperature RTD 1
66	TBase	Float	Base Temperature	Base temperature for corrections
67	MnTemp	Float	Minimum Temperature	Minimum temperature scaling point
68	MxTemp	Float	Maximum Temperature	Maximum temperature scaling point
69	TempDmp	Float	Temperature Dampening	Filter number for temperature
70	Dens	Float	Density	Process density
71	SG	Float	Specific Gravity	Process density / specific gravity factor
72	DAlpha	Float	Density Alpha	Density alpha linearization factor
73	DBeta	Float	Density Beta	Density beta linearization factor
74	SGFct	Float	Specific Gravity Factor	Specific gravity calculation factor
75	DKTFct	Float	Density KT Factor	Density KT factor
76	DDWt	Float	Density DW Factor	Density DW calculation reference temperature
77	DDmp	Float	Density Dampening	Filter number for density
78	DMode	Float	Density Mode	Controls density calculation mode
79	MnuConc	Byte	Concentration Menu	Shows / hides concentration menu
80	mTot	Float	Mass Totalizer	Resettable mass totalizer
81	—	Byte	Reset Mass Totalizer	Resets all resettable mass totalizers except overall mass total
82	AllTot	Float	Overall Mass Totalizer	Non-resettable mass totalizer
83	mTotWL	Float	Mass Totalizer Wrap Limit	Wrap limit of mass totalizers
84	RemTot	Float	Remote Mass Totalizer	Contains mass totalizer (80) value read from remote transmitter via serial line
85	NetmTot	Float	Net Mass Totalizer	Difference (or sum) of the totalizers for two interconnected meters
86	NFloM	Byte	Net Flow Mode	Mode of net flow calculation
87	MnuNet	Byte	Net Flow Menu	Shows / hides net flow menu
88	MnuTot	Byte	Totalizer Menu	Shows / hides totalizer menu
89	MnuAlarm	Byte	Alarm Menu	Shows / hides alarm menu
90	BTot	Float	Batch Totalizer	Mass total during batching
91	—	Byte	Start Batch	Starts batching
92	—	Byte	Stop Batch	Cancels batching
93	BSpt	Float	Batch Setpoint	Desired size of batching
94	BMode	Byte	Batch Mode	Determines the flow parameter used during batching
95	BTPrt	Float	Batch Timing Pre-Trigger	Trigger the opto drivers at a certain time before the batch would otherwise stop
96	BQPrt	Float	Batch Quantity Pre-Trigger	Trigger the opto drivers at a certain amount before the batch would otherwise stop
97	BPrst	Float	Batch Preset	Turns off the batch relays early by this amount (the amount anticipated to dribble after the batch relays close)
98	BSpErr	Byte	Batch Stop on Error	Stops batch if error or alarm warnings happen
99	BType	Byte	Batch Type	Controls type of batching
100	vFlo	Float	Volumetric Flow Rate	Calculated by dividing mass flow rate by density
101	vTot	Float	Volumetric Total	Resettable volumetric totalizer
102	RemVTot	Float	Reverse Volumetric Total	Reverse volumetric totalizer
103	NetVTot	Float	Net Volumetric Total	Net volumetric totalizer
104	mFloA	Float	Mass Flow Rate A	Mass flow rate of component A
105	mFloB	Float	Mass Flow Rate B	Mass flow rate of component B
106	mTotA	Float	Mass Totalizer A	Mass totalizer of component A
107	mTotB	Float	Mass Totalizer B	Mass totalizer of component B
108	m%A	Float	Mass Percentage A	Mass percentage of component A
109	m%B	Float	Mass Percentage B	Mass percentage of component B

Addr	Symbol	Data Type	Parameter Name	Parameter Description
110	CompAD	Float	Density of Component A	Density of component A
111	CompBD	Float	Density of Component B	Density of component B
112	BxMode	Byte	Brix Mode	Soluble or insoluble switch
113	A1	Float	Brix A1	Brix A1 coefficient
114	A2	Float	Brix A2	Brix A2 coefficient
115	A3	Float	Brix A3	Brix A3 coefficient
116	B1	Float	Brix B1	Brix B1 coefficient
117	B2	Float	Brix B2	Brix B2 coefficient
118	B3	Float	Brix B3	Brix B3 coefficient
119	SlugFlo	Float	Slug in Flow	Freezes mass flow rate at last reading where the flow rate was stable
120	IOut1	Float	Current #1 Output	Actual current on Current #1 output
121	IOut2	Float	Current#2 Output	Actual current on Current #2 output
122	FrqOut	Float	Frequency #1 Output	Actual frequency on Frequency output port
123	—	Record	Current#1 Output Setup	Controls Current #1 output
124	—	Record	Current#2 Output Setup	Controls Current #2 output
125	—	Record	Frequency #1 Output Setup	Controls the Frequency output setup
126	+AltI1	Byte	Enable Alternate Current #1	Enables alternate current on Current #1 output
127	+AltI2	Byte	Enable Alternate Current #2	Enables alternate current on Current #2 output
128	+AltFrq	Byte	Enable Alternate Frequency #1	Enables alternate frequency and PWM on Frequency #1 output
129	FrqOEN	Byte	Enable Frequency #1 Output	Enables Frequency #1 output
130	PlsOM	Byte	Pulse Output Mode	Selects the frequency, pulse, or pulse width modulation mode on Frequency #1 output
131	PlsID	Byte	Pulse Output Item	ID of item attached to pulse output
132	PlsSze	Float	Pulse Size	Size of increment after which a pulse is generated
133	PlsWth	Unsigned Integer	Pulse width	Width of pulse in ms
134	C3	Float	Brix C3	Brix C3 coefficient
135	Anin2	Float	Analog Input #2	Voltage measured on Analog Input #2
136	Temp2	float	Temperature #2	Temperature of RTD2
137	AlarmRec	Record	Alarm Setup	Controls transmitter alarms
138	MnuBatch	Byte	Batch Menu	Shows / hides batch menu
140	PWLvl	Byte	Password Level	Currently set password level in transmitter
141	PWRef	Record	Reference Passwords	Reference passwords in transmitter
142	PWSet	Unsigned Integer	User Password	Password entered by user
150	PIDEN	Byte	PID Controller	Enables / disables PID controller
151	PSpt	Float	PID Setpoint	Desired value to keep constant
152	POUT	Float	PID Output	Output percentage of PID controller
153	SamTim	Unsigned Integer	PID Sampling Time	PID controller runs in every sampling time ms
154	PGn	Float	PID Gain	Gain of the PID controller: $C_g * (CS - X)$
155	PDer	Float	PID Derivation Factor	Derivation factor of the PID controller: $C_d * (Error - Error^1)$
156	Plnt	Float	PID Integrating Factor	Integrating factor of the PID controller: $C_i * SUM(Error)$
157	POfset	Float	PID Offset	This value is always added to the PID output
158	MnuPID	Byte	PID Menu	Shows / hides the PID menu
159	PIDID	Byte	PID Assigned To Item	PID controller is assigned to this parameter
170	ChkSum	Unsigned Integer	Check Sum of Program	Check sum of program
172	WI2	Float	W2 Work Item	W2 floating point variable for APP programs
173	IDB	Byte	APP Enable Bits	APP enable bits
174	WBit	Byte	Wb Work Bit	Wb bit type variable for APP programs
175	WI1	Float	W1 Work Item	W1 floating point variable for APP programs
176	API	String	API	API gravity
177	Baume	String	Degrees Baume	Degrees Baume
180	ISOC	Byte	Isolated Current Output Control	Isolated current output control
181	C1	Float	Brix C1	Brix C1 coefficient

Addr	Symbol	Data Type	Parameter Name	Parameter Description
182	C2	Float	Brix C2	Brix C2 coefficient
183	CoilA	Float	Coil A Voltage	Voltage of sensor coil A
184	DrvOut	Float	Driver Output	Driver voltage value in %
185	CoilB	Float	Coil B Voltage	Voltage of sensor coil B
186	DrvGn	Float	Driver Gain	PID Gain for driver control
187	DrvDe	Float	Driver Derivation Factor	Derivation factor of the PID driver control
188	DrvInt	Float	Driver Integrating Factor	Integrating factor of the PID driver control
189	DrvAs	Byte	Driver Source	Selects the input source of driver
190	DrvSP	Float	Driver Setpoint	Desired voltage on sensor reference coil (default is A)
191	DrvRat	Float	Secondary Driver Ratio	Voltage ratio between driver A and driver B
192	DrvAM	Byte	Driver A Mode	Determines the source signal for driver A
193	DrvBM	Byte	Driver B Mode	Determines the source signal for driver B
194	HmrM	Byte	Hammer Mode	Controls the way how we can help the tubes start vibrating
195	BP1	Float	Batch Preset 1	Desired size of batching
196	BP2	Float	Batch Preset 2	Desired size of batching
197	BP3	Float	Batch Preset 3	Desired size of batching
198	BP4	Float	Batch Preset 4	Desired size of batching
199	BP5	Float	Batch Preset 5	Desired size of batching
200	BP6	Float	Batch Preset 6	Desired size of batching
201	ComPr1	Byte	COM1 Protocol	Communication protocol used on COM1 port
202	HARTAdd	Unsigned Integer	Polling Address	Polling address for HART protocol
216	Time	String	Time	Time of day in hh:mm:ss format
217	Date	String	Date	Current date in mm:dd:yy format
223	Tag	String	Tag	Optional tag info of transmitter
224	Name	String	Descriptor	Optional descriptor of transmitter
225	Act#	String	Account Number	Account number
226	Anin1	Float	Analog Input #1	Voltage measured on Analog Input #1
227	An1SI	Float	Analog 1 Slope	Slope for analog 1 input calculation
228	An1Of	Float	Analog 1 Offset	Offset for analog 1 input calculation
229	IOut3	Float	Current #3 Output	Actual current on Current #3 output
230	—	Record	Current #3 Output Setup	Controls Current #3 output
231	+AltI3	Byte	Enable Alternate Current #3	Enables alternate current on Current #3 output
232	An2SI	Float	Analog 2 Slope	Slope for analog 2 input calculation
233	An2Of	Float	Analog 2 Offset	Offset for analog 2 input calculation
234	RTD2Of	Float	RTD2 Linearization Offset	Offset linearization factor of the Pt-100 sensor
235	RTD2SI	Float	RTD2 Linearization Slope	Slope linearization factor of the Pt-100 sensor
236	DspTpe	Byte	Display Type	Type of LCD module used
237	CoilAv	Float	Average Coil Voltage	Average coil of sensor coil A and B
239	FMTot	Float	Mass Totalizer Forward	Forward mass totalizer
240	RMTot	Float	Mass Totalizer Reverse	Reverse mass totalizer
241	Relay	Byte	Batch Relay	Enables / disables batch relay outputs (opto 1-4)
242	WI3	Float	W3 Work Item (P)	Floating point variable for APP programs
243	WI4	Float	W4 Work Item (d)	Floating point variable for APP programs
244	StdVol	String	Volume under standard conditions	Volume under standard conditions
245	StdvFlow	String	Volumetric flow rate referred to standard conditions	Volumetric flow rate referred to standard conditions
246	AnDmp	Byte	Analog Inputs Dampening	Filter number for analog inputs
247	NorFrq	Float	Normalized Tube Frequency	Normalized vibration frequency of sensor tubes
248	WI7	Float	W7 Work Item (v)	Floating point variable for APP programs
249	WI8	Float	W8 Work Item (dv)	Floating point variable for APP programs
250	WI9	Float	W9 Work Item (kv)	Floating point variable for APP programs
253	PWMFrq	Byte	PWM Carrier	Period time of PWM carrier frequency
254	PWMO	Float	Alternate PWM	Simulated pulse width if 128 (Enable Alternate Frequency) is enabled
256	BTime	Float	Batch Time	Batch run time
258	FrqDmp	Byte	Tube Frequency Filter	Filter number for tube frequency

Addr	Symbol	Data Type	Parameter Name	Parameter Description
259	PHold	Unsigned Integer	PID Hold	Hold state of the PID controller
260	ComPr2	Byte	COM2 Protocol	Communication protocol used on COM2 port
272	PhsMsrA	Float	Included Total Area	Included total area code sum
273	AFacPhs	Float	Area-to-Phase Conversion Factor	Converts included total area to phase
274	PhsMsr	Unsigned Integer	ADC Sample Count	Count of ADC samples in a full IF CPU cycle
275	BackUp#	Unsigned Integer	Count of Flash Backups	Count of flash backups
276	Restore#	Unsigned Integer	Count of Flash Restores	Count of flash restores
277	BackUp	Byte	Backup Transmitter	Makes backups of main variables to flash memory
278	FlsRes	Byte	Restore Transmitter	Restores main variables from flash memory backup
279	FlshClr	Byte	Clear Transmitter Backup	Clears flash memory backup (Warning: All factory settings will be lost)
280	SenDmp	Byte	Coil Voltage Filter	0-99% coil voltage filtering
281	PhsBL	Byte	Included Total Area Filter	Length of included total area ring buffer
282	FiltA	Float	Filtered Included Total Area	Filtered included total area code sum
283	RTD1	Float	RTD1 Resistance	Calculated RTD1 resistance
284	RTD2	Float	RTD2 Resistance	Calculated RTD2 resistance
285	FWC	String	Name of Firmware	Shows implemented functions in firmware
286	APP	String	Name of APP Program	Shows implemented functions in application program
287	APSts	Byte	APP Program Status	Enables/disables app program. Cleared at next reset
288	BEst	Byte	Batch Estimation	Estimates the end of batch to minimize the batch counter overflow
289	CYM	N/A	Maximum Cycle Time of Main CPU	Maximum cycle time of main CPU
290	EAlmOut	Byte	Enable Alarm Output	Enables/disables alarm signal on OPTO#4 output
291	BFloAv	String	Average Flow Rate (Batch)	Average flow rate during batching
292	TPd	String	Ticket Printer Format	Ticket printer report definition
293	TPReq	Byte	Print Ticket	Starts printing ticket printer report
294	TPBaud	String	Ticket Printer Baud Rate	Baud rate of ticket printer
295	FlsChg#	String	Count of Changed Parameters	Count of changed parameters not backed up yet
296	UnitSys	Byte	Unit System	Unit system of transmitter
297	HamStrt	Float	Hammer Start Delay	Wait time before starting hammering
298	HamTime	Float	Hammer on Time	Time while the digital hammering is on
299	AppCtrl	Byte	App Program Control	Controls which APP program should be executed
300	Scroll	Byte	Scroll	Determines the menu scrolling direction
301	TxmType	Byte	Transmitter Type	Type of transmitter
302	PwExp	Unsigned Integer	Password Expiring Policy	Determines which password expires at midnight, per COM protocol basis
303	KbLock	Byte	Keyboard Lock Control	Enables / disables automatic keyboard lock after 1 minute of keyboard idle time
304	Lang	Byte	Display Language of Transmitter	Language of the user interface in the transmitter
554	BI	Byte	Batch Parent Item	Parent item of Batch Totalizer and Setpoint items
700	Param1	Byte	User Parameter #1	User parameter in HOME menu
701	Param2	Byte	User Parameter #2	User parameter in HOME menu
702	Param3	Byte	User Parameter #3	User parameter in HOME menu
703	Param4	Byte	User Parameter #4	User parameter in HOME menu
704	Param5	Byte	User Parameter #5	User parameter in HOME menu
705	Param6	Byte	User Parameter #6	User parameter in HOME menu
706	Param7	Byte	User Parameter #7	User parameter in HOME menu
707	Param8	Byte	User Parameter #8	User parameter in HOME menu

## PARAMETERS BY MENU LOCATION

Description of column headers in the following tables:

- Value = Write value or selection
- Unit / Decimal = Change units or number of digits after the decimal, if applicable

### Main Menu > Measurement

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
mFlo	59	Mass Flow Rate	X		X	X		X	X		X
%mFlo	58	Percent of Mass Flow Rate	X		X	X		X	X		X
Dens	70	Density	X		X	X		X	X		X
SG	71	Specific Gravity	X		X	X		X	X		X
Temp1	65	RTD1 Temperature	X		X	X		X	X		X
Temp2	136	RTD2 Temperature	X		X	X		X	X		X
vFlo	100	Volumetric Flow Rate	X		X	X		X	X		X
RESET TOTALS	81	RReset Totaliz	X		X	X		X	X		X
mTot	80	Mass Totalizer	X		X	X		X	X		X
vFlo	239	Forward Mass Total	X		X	X		X	X		X
RmTot	240	Reverse Mass Total	X		X	X		X	X		X
vTot	101	Volumetric Total	X		X	X		X	X		X
AllTot	82	Overall Mass Totalizer	X		X	X		X	X		X

### Main Menu > System > Sensor

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
CoilA	183	Voltage on Sensor Coil A	X		X	X		X	X		X
CoilB	185	Voltage on Sensor Coil B	X		X	X		X	X		X
DrvOut	184	Voltage on Drive Coil	X		X	X		X	X		X
Phase	33	Phase Shift	X		X	X		X	X		X
Freq	60	Tube Frequency	X		X	X		X	X		X
Temp1	65	RTD1 Temperature	X		X	X		X	X		X
Temp2	136	RTD2 Temperature	X		X	X		X	X		X
NorFrq	247	Normalized Vibration Frequency of Sensor Tubes	X		X	X		X	X		X
CoilAv	237	Voltage Average of CoilA and CoilB	X		X	X		X	X		X
CPUT	270	Internal Temperature of Processor	X		X	X		X	X		X



## Main Menu &gt; System &gt; IO Stat

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
IOut1	120	Current Output on Current Output Channel 1	X		X	X		X	X		X
IOut2	121	Current Output on Current Output Channel 2	X		X	X		X	X		X
IOut3	229	Current Output on Current Output Channel 3	X		X	X		X	X		X
FrqOut	122	Frequency Output	X		X	X		X	X		X
AnIn1	226	Current Input on Current Input Channel 1	X		X	X		X	X		X
AnIn2	135	Current Input on Current Input Channel 2	X		X	X		X	X		X
InSts	14	In Status	X			X			X		
OutSts	15	Out Status	X			X			X		

## Main Menu &gt; System &gt; About

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
Sdate	0	Date of Transmitter Software	X			X			X		
FWV	3	Firmware Version	X			X			X		
Restore#	276	Restore Count	X			X			X		
BackUp#	275	Backup Count	X			X			X		
FlsChg#	295	Count of Changed Parameters, Not Backed Up Yet	X			X			X		
Time	216	Time	X			X			X	X	X
Date	217	Date	X			X			X	X	X
Act#	225	Account Number (not used)	X			X	X	X	X	X	X
Name	224	Optional Descriptor of Transmitter	X			X	X	X	X	X	X
Tag	223	Optional Tag Info of Transmitter	X			X	X	X	X	X	X
Sen#	6	Sensor Serial Number	X			X			X	X	X
Ntwk#	5	Network Serial Number	X			X			X	X	X
SMT	4	Type of Installed Sensor	X			X			X	X	X
APP	286	Name of Installed Application Program(s)	X			X			X		
FWC	285	Shows Implemented Functions in Firmware	X			X			X		



**Main Menu > Set Up > Calibration > Flow**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
FloFct	46	Flow Factor	X		X	X		X	X		X
PhsBL	281	Phase Buffer Length							X	X	
PhsFil	40	Phase Filter	X			X			X		
+RFlow	43	Enable Reverse Flow				X	—		X	—	
SlugFlo	119	Slug in Flow	X		X	X		X	X	X	X
DCrt	53	Density Correction Factor for Mass Flow	X		X	X		X	X		X
mDmp	54	Mass Flow Dampening	X			X	X		X	X	
mTFct	49	Mass Flow Temperature Factor	X		X	X		X	X		X
MnFlo	48	Mass Flow Cutoff	X		X	X		X	X	X	X
MxFlo	47	Maximum Mass Flow	X		X	X		X	X	X	X
TBase	66	Temperature Base	X		X	X		X	X	X	X
mLinFct	50	Mass Linearization Factor	X		X	X		X	X	X	X

**Main Menu > Set Up > Calibration > Density**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
DAAlpha	72	Density Alpha	X		X	X		X	X		X
DBeta	73	Density Beta	X		X	X		X	X		X
SGFct	74	Specific Gravity Factor	X		X	X		X	X		X
DKTFct	75	Density KT Factor	X		X	X		X	X		X
DDWt	76	Density DW Reference Temperature	X		X	X		X	X		X
DTCrt	39	Density Correction Temperature							X		
DDmp	77	Density Dampening	X			X	X		X		
DMode	78	Density Mode							X		

**Main Menu > Set Up > Calibration > Temperature**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
Temp1	65	RTD1 Temperature	X		X	X			X	X	X
RTD1Of	51	RTD1 Offset	X		X	X		X	X		X
RTD1SI	52	RTD1 Slope	X		X	X		X	X		X
MnTemp	67	Minimum Temperature Range of RTD1	X		X	X		X	X		X
MxTemp	68	Maximum Temperature Range of RTD1	X		X	X		X	X		X
TempDmp	69	Temperature Dampening	X			X	X		X	X	
RTD2Of	234	RTD2 Offset	X		X	X		X	X	X	X
RTD2SI	235	RTD2 Slope	X		X	X		X	X	X	X
RTD1	283	RTD1 Resistance Value	X		X	X		X	X		X
RTD2	284	RTD Resistance Value	X		X	X		X	X		X

## Main Menu &gt; Set Up &gt; Calibration &gt; Driver

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
DrvGn	186	Driver Gain							X	X	X
DrvDe	187	Driver Derivation Factor							X	X	X
DrvInt	188	Driver Integrating Factor							X	X	X
DrvAs	189	Driver Source							X	—	
DrvSP	190	Driver Setpoint							X	X	X
DrvAM	192	Driver A Mode							X	—	
DrvBM	193	Driver B Mode							X	—	
HmrM	194	Hammer Mode							X	—	
SenDmp	280	Sensor Damping							X	X	
HamStrt	297	Hammer Start Delay	X			X			X		
HamTime	298	Hammer On Time	X			X			X		

## Main Menu &gt; Set Up &gt; Calibration &gt; Zero Calibration

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
Start Zero	21	Starts a Zero Calibration	X	—		X	—		X	—	
Stop Zero	22	Stops a Zero Calibration	X	—		X	—		X	—	
Zero	20	Measure Phase When No Flow is Present	X		X	X		X	X	X	X
Phase	33	Phase Shift	X		X	X		X	X		X
ZroCntr	28	Progress Counter of Zero Calibration	X			X			X		
Zrom	64	Meter Zero in Mass Flow Units	X		X	X		X	X	X	X
Temp1	65	RTD1 Temperature	X		X	X		X	X		X
Freq	60	Tube Frequency	X		X	X		X	X		X
ZroAvg	23	Standard Deviation of the Last Zero Process	X		X	X		X	X	X	X
SenWL	24	Sensor Warning Limit	X		X	X		X	X	X	X
ZroRng	25	Meter Zero Range	X		X	X		X	X	X	X
ZroTFac	26	Temperature Correction of Meter Zero Value							X	X	
ZroL	29	Zero Calibration Start Limit	X	X	X	X	X	X	X	X	X
PhsFil	40	Phase Filter	X			X			X		
PhsNor	44	Phase Normalization	X	X	X	X			X		X

## Main Menu &gt; Set Up &gt; Calibration &gt; Primary

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
SenSze	16	Sensor Size	X			X			X		
SenMat	38	Sensor Tube Material	X			X			X		
MnFreq	62	Minimum Allowable Frequency	X		X	X	X	X	X	X	X
MxFreq	63	Maximum Allowable Frequency	X		X	X	X	X	X	X	X
FrqDmp	258	Frequency Dampening	X			X	X		X	X	
BackUp	277	Backup Transmitter	X			X	—		X	—	

**Main Menu > Set Up > System IO > Current1 Setup**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
IOut1	120	Current Output on Current Channel 1	X		X	X		X	X		X
ID	—	Parameter ID	X			X	—		X	—	
EN	—	Enables Current Output	X			X	—		X	—	X
IVluMn	—	Current Value Associated with Minimum Flow	X		X	X	X	X	X	X	X
IVluMx	—	Current Value Associated with Maximum Flow	X		X	X	X	X	X	X	X
VluMn	—	Parameter Value Associated with Minimum Flow	X		X	X	X	X	X	X	X
VluMx	—	Parameter Value Associated with Maximum Flow	X		X	X	X	X	X	X	X
TstOut	—	Tests Current Channel 1 Output	X		X	X	X	X	X	X	X
+AltI1	126	Enables Alternate Current on Current Channel 1 Output	X			X	—		X	—	

**Main Menu > Set Up > System IO > Current2 Setup**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
IOut2	121	Current Output on Current Channel 2	X		X	X		X	X		X
ID	—	Parameter ID	X			X	—		X	—	
EN	—	Enables Current Output	X			X	—		X	—	X
IVluMn	—	Current Value Associated with Minimum Flow	X		X	X	X	X	X	X	X
IVluMx	—	Current Value Associated with Maximum Flow	X		X	X	X	X	X	X	X
VluMn	—	Parameter Value Associated with Minimum Flow	X		X	X	X	X	X	X	X
VluMx	—	Parameter Value Associated with Maximum Flow	X		X	X	X	X	X	X	X
TstOut	—	Tests Current Channel 2 Output	X		X	X	X	X	X	X	X
+AltI2	127	Enables Alternate Current on Current Channel 2 Output	X			X	—		X	—	

## Main Menu &gt; Set Up &gt; System IO &gt; Current3 Setup

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
IOut3	229	Current Output on Current Channel 3	X		X	X		X	X		X
ID	—	Parameter ID	X			X	—		X	—	
EN	—	Enables Current Output	X			X	—		X	—	X
IVIMn	—	Current Value Associated with Minimum Flow	X		X	X	X	X	X	X	X
IVluMx	—	Current Value Associated with Maximum Flow	X		X	X	X	X	X	X	X
VluMn	—	Parameter Value Associated with Minimum Flow	X		X	X	X	X	X	X	X
VluMx	—	Parameter Value Associated with Maximum Flow	X		X	X	X	X	X	X	X
TstOut	—	Tests Current Channel 3 Output	X		X	X	X	X	X	X	X
+AltI3	231	Enables Alternate Current on Current Channel 3 Output	X			X	—		X	—	

## Main Menu &gt; Set Up &gt; System IO &gt; Frequency Setup

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
FrqOut	122	Frequency Output	X		X	X		X	X		X
FrqOEN	129	Enables Frequency/Pulse Output	X			X	—		X	—	
EN	—	Enables Frequency/Pulse	X			X	—		X	—	X
ID	—	Parameter ID for Frequency 1 Output	X			X	—		X	—	
FrqMn	—	Frequency Value Associated with Minimum Flow	X		X	X	X	X	X	X	X
FrqMx	—	Frequency Value Associated with Maximum Flow	X		X	X	X	X	X	X	X
VluMn	—	Parameter Value Associated with Minimum Flow	X		X	X	X	X	X	X	X
VluMx	—	Parameter Value Associated with Maximum Flow	X		X	X	X	X	X	X	X
TstOut	—	Tests Frequency Output	X		X	X	X	X	X	X	X
+AltFrq	128	Enables Alternate Frequency and PWM on Frequency Output	X			X	—		X	—	
PlsOM	130	Frequency/Pulse selection	X			X	—		X	—	
PlsID	131	Pulse Output Item	X			X	—		X	—	
PlsSze	132	Pulse Size	X		X	X	X	X	X	X	X
PlsWth	133	Pulse Width	X			X	—		X	—	
PWMPer	—	Period of Time in ms	X			X	—		X	—	
PWMAlt	—	Percent of PWMPer	X		X	X	X	X	X	X	X

**Main Menu > Set Up > System IO > Com Ports**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
ComAdd	1	Communication Address	X			X			X	X	
BaudRate	312	Baud Rate	X		X	X		X	X	X	
ComPr1	201	Communication Protocol on COM Port 1	X			X			X	X	
HARTAdd	202	Polling Address	X			X			X	X	
ComPr2	260	Communication Protocol on COM Port 2	X			X			X	X	
Parity	313	Parity for Modbus	X			X			X	X	
Endian	314	Word Order for Modbus	X			X			X	X	
StopBits	315	Stop Bits for Modbus	X			X			X	X	

**Main Menu > Set Up > System IO > Relays**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
Relay	241	Relay	X			X			X	X	
InSts	14	In Status	X			X			X		
OutSts	15	Out Status	X			X			X		

**Main Menu > Set Up > System IO > Analog Input**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
AnIn1	226	Analog Input 1	X		X	X		X	X		X
An1Sl	227	Analog Input 1 Slope	X		X	X		X	X	X	X
An1Of	228	Analog Input 1 Offset	X		X	X		X	X	X	X
AnDmp	246	Analog Input Dampening	X			X	X		X	X	
AnIn2	135	Analog Input 2	X		X	X		X	X		X
An2Sl	232	Analog Input 2 Slope	X		X	X		X	X	X	X
An2Of	233	Analog Input 2 Offset	X		X	X		X	X	X	X

**Main Menu > Set Up > Menus**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
Scroll	300	Changes Scrolling Direction							X	—	
DspTpe	236	Display Type	X			X			X		
MnuBatch	138	Enable/Disable Batch Menu	X			X			X	—	
MnuPID	158	Enable/Disable PID Menu	X			X			X	—	
MnuTot	88	Enable/Disable Totals Menu	X			X			X	—	
MnuAlarm	89	Enable/Disable Alarm Menu	X			X			X	—	
MnuConc	79	Enable/Disable Concentration Menu	X			X			X	—	
MnuApp	37	Enable/Disable Application Menu	X			X	—		X	—	
MnuNet	87	Enable/Disable Net Flow Menu	X			X			X	—	

## Main Menu &gt; Set Up &gt; Program

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
BType	99	Start/Stop Batch	X			X			X	—	
BMode	94	Batch Mode	X			X			X	—	
BTPrT	95	Batch Timing Pre-trigger	X		X	X		X	X	X	X
BQPrT	96	Batch Quantity Pre-trigger	X		X	X		X	X	X	X
BPrst	97	Batch Preset	X		X	X		X	X	X	X
BSpErr	98	Stops Batch if Error or Alarm Occurs	X			X			X	—	
NFloM	86	Mode of Net Flow Calculation	X			X			X	—	
BxMode	112	Brix Mode	X			X			X	—	
CompAD	110	Density of Component A	X		X	X		X	X	—	X
CompBD	111	Density of Component B	X		X	X		X	X	—	X
A1	113	Brix A1 Coefficient	X		X	X		X	X	X	X
A2	114	Brix A2 Coefficient	X		X	X		X	X	X	X
A3	115	Brix A3 Coefficient	X		X	X		X	X	X	X
B1	116	Brix B1 Coefficient	X		X	X		X	X	X	X
B2	117	Brix B2 Coefficient	X		X	X		X	X	X	X
B3	118	Brix B3 Coefficient	X		X	X		X	X	X	X
C1	181	Brix C1 Coefficient	X		X	X		X	X	X	X
C2	182	Brix C2 Coefficient	X		X	X		X	X	X	X
C3	134	Brix C3 Coefficient	X		X	X		X	X	X	X

## Main Menu &gt; Set Up &gt; Password

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
PWSet	142	Sets Password Access Level	X	X		X	X		X	X	
PWLvl	140	Active Password Level	X			X			X		
Pr1	—	Default Password PIN for Operator							X	X	
Pr2	—	Default Password PIN for Technician							X	X	
Pr3	—	Default Password PIN for Engineer							X	X	

## Main Menu &gt; Set Up &gt; Display

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
Lang	304	Language displayed on transmitter	X	X	X	X	X	X	X	X	X
UnitSys	296	Default Engineering Units Setting	X	—		X	—		X	—	
Contrast	9	Contrast Setting	X	X	X	X	X	X	X	X	X
DspTpe	236	Display Type	X			X			X		
TxmType	301	Transmitter Type	X			X			X		
KbLock	303	Keyboard Lock Control	X			X			X	X	
Param1	700	Parameter ID for Home Screen Parameter Line 1	X	X		X	X		X	X	
Param2	701	Parameter ID for Home Screen Parameter Line 2	X	X		X	X		X	X	
Param3	702	Parameter ID for Home Screen Parameter Line 3	X	X		X	X		X	X	
Param4	703	Parameter ID for Home Screen Parameter Line 4	X	X		X	X		X	X	
Param5	704	Parameter ID for Home Screen Parameter Line 5	X	X		X	X		X	X	
Param6	705	Parameter ID for Home Screen Parameter Line 6	X	X		X	X		X	X	
Param7	706	Parameter ID for Home Screen Parameter Line 7	X	X		X	X		X	X	
Param8	707	Parameter ID for Home Screen Parameter Line 8	X	X		X	X		X	X	

## Main Menu &gt; Batch

(Menu must be enabled.)

See "RCT1000 Batch Control" user manual, available at [www.badgermeter.com](http://www.badgermeter.com), for setup and operation.

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
Start/Stop		Start or Stop Batch	X		X	X		X	X		X
BSpt	93	Batch Setpoint	X	X	X	X	X	X	X	X	X
BTot	90	Batch Total	X		X	X		X	X		X
mTot	80	Mass Total	X		X	X		X	X		X
mFlo	59	Mass Flow Rate	X		X	X		X	X		X
%mFlo	58	Percentage of Mass Flow Rate from Sensor Max	X		X	X		X	X		X
BFloAv	291	Batch Flow Average	X		X	X		X	X		X
Temp1	65	RTD1 Temperature	X		X	X		X	X		X
BP1	195	Batch Preset 1	X		X	X	X	X	X	X	X
BP2	196	Batch Preset 2	X		X	X	X	X	X	X	X
BP3	197	Batch Preset 3	X		X	X	X	X	X	X	X
BP4	198	Batch Preset 4	X		X	X	X	X	X	X	X
BP5	199	Batch Preset 5	X		X	X	X	X	X	X	X
BP6	200	Batch Preset 6	X		X	X	X	X	X	X	X
BEst	288	Batch Estimation	X			X			X		

**Main Menu > PID**

(Menu must be enabled.)

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
PSpt	151	PID Setpoint	X	X	X	X	X	X	X	X	X
PID EN	150	PID Enable	X	—		X	—		X	—	
PID ID	159	PID Parameter Identifier	X			X			X	—	
POut	152	Output Percentage of PID Controller	X		X	X		X	X		X
SamTim	153	PID Sampling Time	X			X			X	—	
PGn	154	PID Gain	X		X	X		X	X	X	X
PDer	155	PID Derivative Factor	X		X	X		X	X	X	X
PInt	156	PID Integer Factor	X		X	X		X	X	X	X
POfset	157	PID OffSet	X	X	X	X		X	X	X	X
PHold	259	PID Hold	X	—		X	—		X	—	

**Main Menu > Total**

(Menu must be enabled.)

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
Reset Totals	—	Forward Mass Total	X		X	X		X	X		X
mTot	80	Mass Total	X		X	X		X	X		X
FmTot	239	Forward Mass Total	X		X	X		X	X		X
RmTot	240	Reverse Mass Total	X		X	X		X	X		X
AllTot	82	Non-Resettable Mass Totalizer	X		X	X		X	X		X
mTotWL	83	Mass Totalizer Wrap Limit	X		X	X		X	X	X	X
TotWCnt	31	Totalizer Wrap Count	X	—		X	—		X	—	
vTot	101	Volumetric Total	X		X	X		X	X		X
mFlo	59	Mass Flow Rate	X		X	X		X	X		X
vFlo	100	Volumetric Flow Rate	X		X	X		X	X		X

**Main Menu > Concentration**

(Menu must be enabled.)

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
mFloA	104	Mass Flow Rate of Component A	X		X	X		X	X		X
mFloB	105	Mass Flow Rate of Component B	X		X	X		X	X		X
mFlo	59	Mass Flow Rate	X		X	X		X	X		X
mTotA	106	Mass Total of Component A	X		X	X		X	X		X
mTotB	107	Mass Total of Component B	X		X	X		X	X		X
m%A	108	Mass Flow of Component A as a Percentage	X		X	X		X	X	X	X
m%B	109	Mass Flow of Component B as a Percentage	X		X	X		X	X	X	X
Temp1	65	RTD1 Temp.	X		X	X		X	X		X
Dens	70	Density	X		X	X		X	X		X



## Main Menu &gt; Application

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
WI1	175	Work Item 1	X	X	X	X	X	X	X	X	X
WI2	172	Work Item 2	X	X	X	X	X	X	X	X	X
WI3	242	Work Item 3	X	X	X	X	X	X	X	X	X
WI4	243	Work Item 4	X	X	X	X	X	X	X	X	X
StdVol	244	Work Item 5	X	X	X	X	X	X	X	X	X
StdVflo	245	Work Item 6	X	X	X	X	X	X	X	X	X
WI7	248	Work Item 7	X	X	X	X	X	X	X	X	X
WI8	249	Work Item 8	X	X	X	X	X	X	X	X	X
WI9	250	Work Item 9	X	X	X	X	X	X	X	X	X
WBit	174	Work Bit	X	X		X	X		X	X	
API	176	API Gravity	X	X		X	X		X	X	
Baume	177	Degrees Baume	X	X		X	X		X	X	
mFlo	59	Mass Flow Rate	X	X	X	X	X	X	X	X	X
Temp1	65	RTD1 Temp.	X		X	X		X	X		X
Dens	70	Density	X		X	X		X	X		X

## Main Menu &gt; Net Flow

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
RemFlo	55	Remote Mass Flow Rate	X		X	X		X	X	X	X
mFlo	59	Mass Flow Rate	X		X	X		X	X		X
NetFlo	56	Net Flow Rate	X		X	X		X	X	X	X
NetvFlo	57	Net Volumetric Flow	X		X	X		X	X		X
RemTot	84	Remote Mass Total	X		X	X		X	X	X	X
NetmTot	85	Net Mass Total	X		X	X		X	X	X	X
mTot	80	Mass Total	X		X	X		X	X		X
NetvTot	103	Net Volumetric Total	X		X	X		X	X		X
RemVTot	102	Remote Volumetric Total	X		X	X		X	X		X

## Main Menu &gt; Alarms &gt; Alarm-A

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
ID A	—	Parameter ID of Alarm A	X			X	—		X	—	
EN A	—	Enable Alarm A	X			X	—		X	—	
ALo	—	Alarm A Low Limit	X		X	X	X	X	X	X	X
AHi	—	Alarm A High Limit	X		X	X	X	X	X	X	X

## Main Menu &gt; Alarms &gt; Alarm-B

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
ID B	173	Parameter ID of Alarm B	X			X	—		X	—	
EN B	—	Enable Alarm B	X			X	—		X	—	
BLo	—	Alarm B Low Limit	X		X	X	X	X	X	X	X
BHi	—	Alarm B High Limit	X		X	X	X	X	X	X	X

**Main Menu > Alarms > Alarm-C**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
ID C	—	Parameter ID of Alarm C	X			X	—		X	—	
EN C	—	Enable Alarm C	X			X	—		X	—	
Clo	—	Alarm C Low Limit	X		X	X	X	X	X	X	X
Chi	—	Alarm C High Limit	X		X	X	X	X	X	X	X

**Main Menu > Alarms > Alarm-D**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
ID D	—	Parameter ID of Alarm D	X			X	—		X	—	
EN D	—	Enable Alarm D	X			X	—		X	—	
Dlo	—	Alarm D Low Limit	X		X	X	X	X	X	X	X
Dhi	—	Alarm D High Limit	X		X	X	X	X	X	X	X

**Main Menu > Alarms > Alarm-E**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
ID E	—	Parameter ID of Alarm E	X			X	—		X	—	
EN E	—	Enable Alarm E	X			X	—		X	—	
Elo	—	Alarm E Low Limit	X		X	X	X	X	X	X	X
Ehi	—	Alarm E High Limit	X		X	X	X	X	X	X	X

**Main Menu > Alarms > Alarm-F**

Parameter	Param. Addr	Description	Password Levels								
			Operator			Technician			Engineer		
			Read	Write		Read	Write		Read	Write	
				Value	Unit / Decimal		Value	Unit / Decimal		Value	Unit / Decimal
ID F	—	Parameter ID of Alarm F	X			X	—		X	—	
EN F	—	Enable Alarm F	X			X	—		X	—	
Flo	—	Alarm F Low Limit	X		X	X	X	X	X	X	X
Fhi	—	Alarm F High Limit	X		X	X	X	X	X	X	X
EAlmOut	290	Enables or Disables Alarm Signal on OPTO#4 Output	X			X			X	—	

## RCT CONSOLE BASICS

RCT Console is a software program for monitoring, diagnostics and configuration for Badger Meter Coriolis transmitters. The following procedure is for setup of the program only. For assistance with configuration, features and functions, refer to the software help file.

### Minimum System Requirements

#### Operating System

Target systems must meet the following minimum operating system requirement:

- Windows XP
- Windows Server 2003
- Windows Vista
- Windows Server 2008
- Windows 7
- Windows Server 2008 R2
- Windows 8, 8.1
- Windows 10

**NOTE:** Microsoft .NET Framework version 3.5 with Service Pack 2 or later must be installed.

#### Hardware

PC to software communication can be done via EIA-485 or through a Mini-B USB cable. USB to serial port, Bluetooth serial port or any combination of RS232, USB and Bluetooth communication port is allowed.

### Setup

1. Install the RCT Console software on the Host PC.

The software program should be up to date. On Startup, the program will check to see if there is a new version available. If a new version is available, follow the prompts to update the program before proceeding to the next step.

**NOTE:** To change the language, see *"Changing the Language on the RCT Console" on page 93*.

2. Connect the RCT1000 Transmitter to the host PC.
3. On the *Transmitter Explorer* tab, click the **Add Device** icon, then click on **Transmitter Manager**.




Figure 75: Transmitter explorer

4. Click the **Add New Transmitter** icon.




Figure 76: Add new transmitters

The *Edit Transmitter* window displays:




Figure 77: Edit transmitter

5. Under *Type*, make sure the *BMI RCT1000 Transmitter* is selected.
6. Under *Name*, give this configuration a name that applies to the location of the transmitter. This helps when there could possibly be multiple meters in one location. RCT Console will save the configuration for each Transmitter.
7. Under *Address*, select the address that is indicated in the transmitter. To find the address, go to *Main Menu > SETUP > SYSTEM IO > COM PORTS > ComAdd*. The value located on the right of this parameter is the address to be entered into the software.
8. Under *Protocol*, select **BMI Protocol**.
9. Click **Test Connection** to check all available COM Ports at all Baud Rates to find the transmitter. A prompt will appear indicating that the transmitter was found. Click **OK** and exit the Transmitter Manager.

The program should now be communicating with the connected transmitter.

## Changing the Language on the RCT Console

1. On the *Tools* tab, select **Options**.




Figure 78: Select tools > options

2. Select the drop-down menu from the *Appearance > Language* dropbox.




Figure 79: Select a language

3. After selecting the language, the text will change. Click **OK** to accept the new language.




Figure 80: Accept the new language

## GLOSSARY

**Batching:** A manufacturing process where exact amounts of product are dosed into a vessel based on a recipe ingredient list.

**Brix:** A unit representation of the sugar content of an aqueous solution.

**Baume:** A unit representation of the sugar concentration in juice or wine

**Cavitation:** A sudden appearance of gaseous phase in a liquid due to a pressure drop below its vapor pressure, which can occur as fluids exit an orifice plate, control valve or on suction of a pump.

**Class 1 Div 1:** An area classification that indicates the area is in the presence of flammable gases or vapors in the air and is normally explosive or hazardous.

**Class 1 Div 2:** An area classification that indicates the area is in the presence of flammable gases or vapors in the air and is not normally present in an explosive concentration, but may accidentally exist.

**Condensate:** Formed by the condensation reaction making a liquid.

**Density:** Density is a physical property, constant at a given temperature. Density can help to identify a substance.

**Feedback:** Feedback control of a system is done by comparing the output with a reference and generating a correcting signal.

**Frequency Response:** The amount the oscillating frequency of the Coriolis sensor tubes changes due to a change in Density of the fluid being measured.

**HART:** A communication protocol that has been used in industrial applications for the configuration and reading of legacy like devices.

**Homogenous Liquid:** A liquid that is composed of parts or elements that are all of the same kind, or single phase.

**Integral:** A term used within the flow meter industry that means the electronics used to read and display flow meter output is directly mounted to the flow meter housing.

**Intrinsically Safe (I.S.):** A protection technique for the safe operation of electronic equipment in explosive or hazardous areas.

**Laminar Flow:** Reynolds number below 2000. Fluid molecules do not mix with each other and flow in straight lines within the pipe. This causes variations in velocity due to pipe wall friction as compared to the center of the pipe where no friction takes place.

**Mass:** A measure of the amount of material in an object, being directly related to the number and type of atoms present in the object. An objects Mass does not change with a body's position, movement or alteration of its shape, unless material is added or removed.

**Modbus:** A communication protocol used for the communication and configuration of devices connected to different types of buses or networks.

**NEMA 4:** A standard from the National Electrical Manufacturers Association which defines enclosure ratings. Type 4 is constructed and rated for either indoor or outdoor use and provides a degree of protection against access to hazardous parts, ingress of solid foreign objects, ingress of water and remain undamaged by the external formation of ice.

**NEMA 4X:** A standard from the National Electrical Manufacturers Association which defines enclosure ratings. Type 4X is constructed and rated to be the same as type 4, but with the addition of a level of protection against corrosion.

**Percent Solids:** The measurement of a solid material that has virtually no density change relative to temperature suspended in a liquid carrier. Titanium dioxide and calcium carbonate are examples of slurry applications.

**Percent Soluble:** The measurement of two liquids in a flow stream. Coriolis meters can determine percent concentration of each component in a two component stream by its density value.

**Phase Shift:** The difference between two sinusoidal wave signals, at which point they cross a zero reference point from positive to negative values.

**PID:** Proportional, Integral and Derivative; terms in the algorithm for automated process control loops or PID loops.

**Pressure Drop:** The process line pressure loss across a barrier in the flow stream as a fluid passes through it.

**Ratio Control:** Is a control scheme that sets the flow rate in one flow loop to a certain value, based upon an input signal from a second flow loop and a ratio multiplier. This can be a liquid : liquid or a liquid : solid ratio system.

**Repeatability:** Similar to uncertainty, this is a percentage within a specification that indicates at any point within the flow range of a meter, the actual output will be the same if that point is selected again at a different time.

**Resonance Error:** Indicates the Coriolis meters resonant frequency is not vibrating within a predetermined range.

**Reynolds Number:** A unit-less number that represents the flow regime within a pipe denoting laminar or turbulent flow conditions.

**Sensor Warning:** An alarm message displayed when the feedback coils of a Coriolis meter are not maintaining the desired set point level. Typically caused by imbalance within the meter due to gas bubbles in a liquid application or settling solids of a slurry application.

**Slug Flow:** A process condition where sections of the pipeline will have large amount of gas bubbles accumulated and travel with the liquid during flow conditions

**Slurry:** A semi-liquid mixture.

**Specific Gravity:** SG of a liquid is a dimensionless unit defined as the ratio of density of the liquid to the density of water at a specified temperature. It is common to use the density of water at 39° F (4° C) as reference. At this point the density of water is at the highest (1000 kg/m<sup>3</sup> or 62.4 lb/ft<sup>3</sup>).

**Temperature Compensation:** To adjust a measurement for thermal changes in a process. Typically used for expansion or spring constant characteristics of a metal component.

**Thixotropic:** The property of certain fluids whereby they become less viscous when agitated and return to being high viscosity when allowed to stand. Ketchup is a good example of this as its property in a normal state is thick and when pressure is applied to it its molecules “sheer” against each other causing it to flow easily.

**Transition Flow:** Reynolds Number between 2000...4000 where both laminar and turbulent conditions can occur within the pipe.

**Turbulent Flow:** Reynolds Number above 4000. Fluid molecules do interact in random motion throughout the pipe and causes virtually the same velocity from the wall to the center of the pipe.

**Uncertainty:** A percentage based number within a specification that is an indication of a meter’s flow output is within a certain percentage. This can also be defined as the accuracy of the measurement from the reading, of full scale or of actual flow rate.

**Viscosity:** A measure of a fluids ability to resist external influences attempting to change its form. High viscosity fluids are thick and resist movement when a pressure is applied to them where as low viscosity fluids tend to more quite easily with little pressure applied to them.

**Weight:** The gravitational force acting on the mass of a body.

**Wetted Material:** Parts within a measuring system that come in contact with the fluid being metered/measured.

**Zero Stability:** Refers to the stability of the phase shift measurement in the Coriolis meter with no flow conditions. Directly related to the balance of the sensing tubes.

## Control. Manage. Optimize.

Trademarks appearing in this document are the property of their respective entities. Due to continuous research, product improvements and enhancements, Badger Meter reserves the right to change product or system specifications without notice, except to the extent an outstanding contractual obligation exists. © 2019 Badger Meter, Inc. All rights reserved.

**[www.badgermeter.com](http://www.badgermeter.com)**

---

The Americas | **Badger Meter** | 4545 West Brown Deer Rd | PO Box 245036 | Milwaukee, WI 53224-9536 | 800-876-3837 | 414-355-0400  
México | **Badger Meter de las Americas, S.A. de C.V.** | Pedro Luis Ogazón N°32 | Esq. Angelina N°24 | Colonia Guadalupe Inn | CP 01050 | México, DF | México | +52-55-5662-0882  
Europe, Eastern Europe Branch Office (for Poland, Latvia, Lithuania, Estonia, Ukraine, Belarus) | **Badger Meter Europe** | ul. Korfantego 6 | 44-193 Knurów | Poland | +48-32-236-8787  
Europe, Middle East and Africa | **Badger Meter Europa GmbH** | Nürtinger Str 76 | 72639 Neuffen | Germany | +49-7025-9208-0  
Europe, Middle East Branch Office | **Badger Meter Europe** | PO Box 341442 | Dubai Silicon Oasis, Head Quarter Building, Wing C, Office #C209 | Dubai / UAE | +971-4-371 2503  
Slovakia | **Badger Meter Slovakia s.r.o.** | Racianska 109/B | 831 02 Bratislava, Slovakia | +421-2-44 63 83 01  
Asia Pacific | **Badger Meter** | 80 Marine Parade Rd | 19-07 Parkway Parade | Singapore 449269 | +65-63464836  
Switzerland | **Badger Meter Swiss AG** | Mittelholzerstrasse 8 | 3006 Bern | Switzerland | +41-31-932 01 11